


Panasonic

Operating Instructions
Microwave Oven

Models: NN-H735/H765/H935/ H965/SN776



Safety Information

Precautions	.Inside cover
Important Safety Instruction	ons1-3
Installation and Grounding	
Instructions	3-4
Safety Precautions	5-6

Operation

Operation	
Control Panel	g
Starting to Use Your Oven	
Setting the Clock	
Function Features	10-11
Selecting Power & Cook Time	12
Quick Min Feature	12
Keep Warm Feature	
Popcorn Feature	13
More/Less Feature	
Inverter Turbo Defrost Feature	14
Defrosting Tips & Techniques	
Sensor Reheat Feature	16
Sensor Cook Feature	
Sensor Cook Chart	17

Operation

.18
.19
-21
.22
-23
.27

Maintenance

Care and Cleaning of Your Microw	ave
Oven	24
Accessory Purchases	24
Before Requesting Service	25
Limited Warranty & Customer Serv	vice
Directory	

General Information

Cookware Guide	7
Oven Components Diagram	8
Specifications	
Íser's Record	28

READ ALL INSTRUCTIONS CAREFULLY BEFORE USING THE OVEN.

Para instrucciones en español, voltee el libro.

For assistance, please call: 1-800-211-PANA(7262) or send e-mail to: consumerproducts@panasonic.com or visit us at www.panasonic.com

(U.S.A)

For assistance, please call: 787-750-4300

or visit us at www.panasonicpr.com

(Puerto Rico)

F00037C51AP iPress0106-3 Printed in China

Microwave Oven Safety

Your safety and the safety of others are very important.

We have provided important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol. It is used to alert you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol and either the word "DANGER", "WARNING" or "CAUTION". These words mean:

A DANGER

You can be killed or seriously injured if you don't immediately follow instructions.

AWARNING

You can be killed or seriously injured if you don't follow instructions.

A CAUTION

You can be exposed to a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- (b) Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) door (bent),
 - (2) hinges and latches (broken or loosened),
 - (3) door seals and sealing surfaces.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

Thank you for purchasing a Panasonic Microwave Oven.

Your microwave oven is a cooking appliance and you should use as much care as you use with a stove or any other cooking appliance. When using this electric appliance, basic safety precautions should be followed, including the following:

A IMPORTANT SAFETY INSTRUCTIONS

—To reduce the risk of burns, electric shock, fire, injury to persons, or exposure to excessive microwave energy:

. Read all instructions before using this appliance.

- Read and follow the specific "PRECAUTIONS TO AVOID POSSIBLE EXPO-SURE TO EXCESSIVE MICROWAVE ENERGY," found on the inside front cover.
- 3. This appliance must be grounded. Connect only to a properly grounded outlet. See "GROUNDING INSTRUCTIONS" found on page 4.
- As with any cooking appliance, DO NOT leave oven unattended while in use.
- 5. Install or locate this appliance only in accordance with the installation instructions found on page 3.

6. **DO NOT** cover or block any openings on this appliance.

- DO NOT store this appliance outdoors. DO NOT use this product near water for example, near a kitchen sink, in a wet basement, or near a swimming pool or similar locations.
- 8. Use this appliance only for its intended use as described in this manual. DO NOT use corrosive chemicals, vapors, or non-food products in this appliance. This type of oven is specifically designed to heat, or cook food. It is not designed for industrial or laboratory use. The use of corrosive chemicals in heating or cleaning will damage the appliance and may result in radiation leaks.
- When cleaning surfaces of the door and oven that come together on closing the door, use only mild, non-abrasive soaps or detergents applied with a sponge or soft cloth.
- DO NOT allow children to use this appliance, unless closely supervised by an adult. DO NOT assume that because a child has mastered one cooking skill he/she can cook everything.
- 11. **DO NOT** operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
- 12. **DO NOT** immerse cord or plug in water.
- 13. Keep cord away from heated surfaces.
- 14. **DO NOT** let cord hang over edge of a table or counter.
- 15. This appliance should be serviced only by qualified service personnel. Contact the nearest authorized service center for examination, repair or adjustment.
- 16. Some products such as whole eggs with or without shell, narrow neck bottles and sealed containers—for example, closed glass jars—may explode and should not be heated in this oven.
- 17. To reduce the risk of fire in the oven cavity:
 - (a) Do not overcook food. Carefully attend appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - (b) Remove wire twist-ties from paper or plastic bags before placing bag in oven.
 - (c) If material inside the oven ignites, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - (d) DO NOT use the cavity for storage purposes. DO NOT leave paper products, cooking utensils or food in the cavity when not in use.

A IMPORTANT SAFETY INSTRUCTIONS

(continued)

18. Superheated Liquids

Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without showing evidence (or signs) of boiling. Visible bubbling is not always present when the container is removed from the microwave oven. THIS COULD RESULT IN VERY HOT LIQUIDS SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.

To reduce the risk of injury to persons:

- (a) STIR THE LIQUID BOTH BEFORE AND HALFWAY THROUGH **HEATING IT.**
- (b) Do not heat water and oil, or fats together. The film of oil will trap steam, and may cause a violent eruption.
- (c) Do not use straight-sided containers with narrow necks.
- (d) After heating, allow the container to stand in the microwave oven for a short time before removing the container.
- 19. **DO NOT** cook directly on the turntable. It can crack, and cause injury or damage to the oven.

TO AVOID THE RISK OF SHOCK:

DO NOT remove outer panel from oven. Repairs must be done only by a qualified service person.

TO REDUCE THE RISK OF EXPOSURE TO MICROWAVE **ENERGY:**

DO NOT tamper with, or make any adjustments or repairs to Door, Control Panel Frame, Safety Interlock Switches, or any other part of oven. microwave leakage may result.

TO AVOID THE RISK OF FIRE:

- 1. DO NOT operate the oven empty. The microwave energy will reflect continuously throughout the oven causing overheating and damage, if food or water is not present to absorb energy.
- 2. **DO NOT** store flammable materials next to, on top of, or in the oven.
- 3. DO NOT dry clothes, newspapers or other materials in the oven, or use newspaper or paper bags for cooking.
- 4. DO NOT hit or strike Control Panel. Damage to controls may occur.
- 5. **DO NOT** use recycled paper products unless the paper product is labeled as safe for microwave oven use. Recycled paper products may contain impurities which may cause sparking.

TO AVOID THE RISK OF SCALDING:

POT HOLDERS should always be used when removing items from the oven. Heat is transferred from the HOT food to the cooking container and from the container to the Glass Tray. The Glass Tray can also be very HOT after removing the cooking container from the oven.

SAVE THESE INSTRUCTIONS

For proper use of your oven, read remaining safety cautions and operating instructions.





A IMPORTANT SAFETY INSTRUCTIONS

(continued)

Glass Trav

1. DO NOT operate the oven without the Roller Ring and the Glass Tray in place.

- 2. **DO NOT** operate the oven without the Glass Tray fully engaged on the drive hub. Improper cooking or damage to the oven could result. Verify that the Glass Tray is properly engaged and rotating by observing its rotation when you press Start. Note: The Glass Tray can turn in either direction.
- 3. Use only the Glass Tray specifically designed for this oven. DO NOT substitute any other glass tray.
- 4. If the Glass Tray is hot, allow to cool before cleaning or placing in water.
- 5. **DO NOT** cook directly on the Glass Tray. Always place food in a microwave safe dish, or on a rack set in a microwave safe dish.
- 6. If food or utensil on the Glass Tray touches oven walls, causing the tray to stop moving, the tray will automatically rotate in the opposite direction.

Roller Ring

- 1. The Roller Ring and oven floor should be cleaned frequently to prevent excessive noise.
- 2. Always replace the Roller Ring and the Glass Tray in their proper positions.
- 3. The Roller Ring must always be used for cooking along with the Glass Tray.



INSTALLATION AND GROUNDING INSTRUCTIONS

Examine Your Oven

Unpack oven, remove all packing material and examine the oven for any damage such as dents, broken door latches or cracks in the door. Notify dealer immediately if oven is damaged. DO NOT install if oven is damaged.

Placement of Oven

- 1. The oven must be placed on a flat, stable surface. Place the front surface of the door three inches or more from the counter top edge to avoid accidental tipping of the microwave oven during normal use. For proper operation, the oven must have sufficient air flow. Allow 3-inches (7.6 cm) of space on both sides of the oven and 1-inch (2.5 cm) of space on top of the oven.
 - (a) **DO NOT** block air vents. If they are blocked during operation, the oven may be overheated and damaged.
 - (b) **DO NOT** place oven near a hot, damp surface such as a gas or electric range, or dishwasher.
 - (c) **DO NOT** operate oven when room humidity is excessive.
- 2. This oven is manufactured for household use only. It is not approved or tested for mobile vehicle, marine, or commercial use.

Installation

- 1. **DO NOT** block air vents. If they are blocked during operation, the oven may overheat. If the oven overheats, a thermal safety device will turn the oven off. The oven will remain inoperable until it has cooled.
- 2. If the oven is designed for installation into a wall cabinet by using the proper trim kit available from a local Panasonic dealer, follow all instructions packed with the kit.



A INSTALLATION AND GROUNDING INSTRUCTIONS

(continued)

AWARNING

IMPROPER USE OF THE GROUNDING PLUG

CAN RESULT IN A RISK OF ELECTRIC SHOCK.

Consult a qualified electrician or service person if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a three wire extension cord that has a three prong polarized grounding plug, and a three slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord should be equal to or greater than the electrical rating of the appliance.

Grounding Instructions

THIS APPLIANCE MUST BE GROUNDED. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

- Plug into properly installed and grounded 3 prong outlet.
- DO NOT remove ground prong.
- DO NOT use an adapter.

Power Supply

- 1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
- Longer cord sets or extension cords are available and may be used if care is exercised in their use. Do not let cord hang over edge of a table or counter.
- 3. If a long cord or extension cord is used. (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance. (2) the extension cord must be a grounding-type 3-wire cord, and (3) the longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled on by children or tripped over accidentally.

Wiring Requirements

The oven must be operated on a SEPARATE CIRCUIT. No other appliance should share the circuit with the microwave oven. If it does, the branch circuit fuse may blow or the circuit breaker may trip. The oven must be plugged into at least a 20 AMP, 120 VOLT, 60 Hz GROUNDED OUTLET. Where a standard two-prong outlet is encountered, it is the personal responsibility and obligation of the consumer to have it replaced with a properly grounded three-prong outlet. The VOLTAGE used must be the same as specified on this microwave oven (120 V, 60 Hz). Using a higher voltage is dangerous and may result in a fire or oven damage. Using a lower voltage will cause slow cooking. Panasonic is NOT responsible for any damages resulting from the use of the oven with any voltage other than specified.

TV / Radio Interference

- 1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
- 2. When there is interference, it may be reduced or eliminated by taking the following measures:
 - (a) Place the radio, TV, etc. away from the microwave oven as far as possible.
 - (b) Use a properly installed antenna to obtain stronger signal reception.
 - (c) Clean door and sealing surfaces of the oven. (See Care and Cleaning of Your Microwave Oven)



Safety Precautions

Follow These Safety Precautions When Cooking in Your Oven.

IMPORTANT

Proper cooking depends upon the power, the time setting and quantity of food. If you use a smaller portion than recommended but cook at the time for the recommended portion, fire could result.

1) HOME CANNING / STERILIZING / DRYING FOODS / SMALL QUANTITIES OF FOODS

- DO NOT use your oven for home canning. Your oven cannot maintain the food at the proper canning temperature. The food may be contaminated and then spoil.
- **DO NOT** use the microwave oven to sterilize objects (baby bottles, etc.). It is difficult to keep the oven at the high temperature needed for sterilization.
- DO NOT dry meats, herbs, fruits or vegetables in your oven. Small quantities
 of food or foods with low moisture content can dry out, scorch or catch on fire if
 overheated.

2) POPCORN

Popcorn may be popped in a microwave oven corn popper. Microwave popcorn which pops in its own package is also available. Follow popcorn manufacturers' directions and use a brand suitable for the cooking power of your microwave oven.

CAUTION: When using pre-packaged microwave popcorn, you can follow recommended package instructions or use the popcorn pad (refer to page 13). Otherwise, the popcorn may not pop adequately or may ignite and cause a fire. Never leave oven unattended when popping popcorn. Allow the popcorn bag to cool before opening, always open the bag facing away from your face and body to prevent steam burns.

3) DEEP FAT FRYING

• **DO NOT** deep fat fry in your microwave oven. Cooking oils may burst into flames and may cause damage to the oven and perhaps result in burns. Microwave utensils may not withstand the temperature of the hot oil, and can shatter or melt.

4) FOODS WITH NONPOROUS SKINS

- DO NOT COOK/REHEAT WHOLE EGGS, WITH OR WITHOUT THE SHELL.

 Steam buildup in whole eggs may cause them to explode, and possibly damage the oven or cause injury. Reheating SLICED hard-boiled eggs and cooking SCRAMBLED eggs is safe.
- Potatoes, apples, whole squash and sausages are examples of foods with nonporous skins. These types of foods must be pierced before microwave cooking to prevent them from exploding.

CAUTION: Cooking dry or old potatoes can cause fire.

Safety Precautions

(continued)

5) GLASS TRAY / COOKING CONTAINERS / FOIL

- Cooking containers get hot during microwaving. Heat is transferred from the HOT food to the container and the Glass Tray. Use pot holders when removing containers from the oven or when removing lids or plastic wrap covers from cooking containers, to avoid burns.
- The Glass Tray will get hot during cooking. It should be allowed to cool before handling or before paper products, such as paper plates or microwave popcorn bags, are placed in the oven for microwave cooking.
- When using foil in the oven, allow at least 1-inch (2.5 cm) of space between foil and interior oven walls or door.
- Dishes with metallic trim should not be used, as arcing may occur.

6) PAPER TOWELS / CLOTHS

• **DO NOT** use paper towels or cloths which contain a synthetic fiber woven into them. The synthetic fiber may cause the towel to ignite. Use paper toweling under supervision.

7) BROWNING DISHES / OVEN COOKING BAGS

- Browning dishes or grills are designed for microwave cooking only. Always follow instructions provided by the manufacturer. DO NOT preheat browning dish more than 6 minutes.
- If an oven cooking bag is used for microwave cooking, prepare according to package directions. DO NOT use a wire twist-tie to close bag, instead use plastic ties, cotton string or a strip cut from the open end of the bag.

8) THERMOMETERS

 DO NOT use a conventional meat thermometer in your oven. Arcing may occur. Microwave safe thermometers are available for both meat and candy.

9) BABY FORMULA / BABY FOOD

• **DO NOT** heat baby formula or baby food in the microwave oven. The glass jar or surface of the food may appear warm while the interior can be so hot as to burn the infant's mouth and esophagus.

10) REHEATING PASTRY PRODUCTS

• When reheating pastry products, check temperatures of any fillings before eating. Some foods have fillings which heat faster and can be extremely hot, while the surface remains warm to the touch (ex. Jelly Donuts).

11) GENERAL OVEN USAGE GUIDELINES

• DO NOT use the oven for any purpose other than the preparation of food.




Cookware Guide

Aluminum Foil Yes for Shielding only Small strips of foil can be molded around thin pp meat or poultry to prevent overcooking. Arcing of if foil is too close to oven wall or door and dama oven will result. Browning Dish Yes only. Check browning dish information for instruct and heating chart. Do not preheat for more than heating chart. Do not use consider the other preheating chart. Do not use cooking or reheating. Heat nolly 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Heat Resistant Oven Glassware & Ceramics No Most glass jars are not heat resistant. Do not use cooking or reheating. Heat only 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Heat Resistant Oven Glassware & Ceramics No Most glass jars are not heat resistant. Do not use cooking or reheating. Heat only 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Heat only 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Heat only 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Heat Resistant Oven Glassware & Ceramics No Most glass jars are not heat resistant. Do not us	
Aluminum Foil Shielding only orly if foil is too close to oven wall or door and dama oven will result. Browning Dish Pes Browning dishes are designed for microwave conly. Check browning dish information for instructional heating chart. Do not preheat for more than May cause a fire in the oven. Check manufacturers' use and care directions for microwave heating. Some dinnerware may state back of the dish, "Oven-Microwave Safe". Unlabeled Dinnerware Pisposable polyester Paperboard Dishes Fast Food Carton with Metal Handle Frozen Dinner Tray Metal Glass Jars No Metal can cause arcing and damage to your oven. Metal Resistant Oven Glassware & Ceramics Metal Twist-Ties No Metal Twist-Ties No Metal Twist-Ties No Metal Sakeware Paper Plates & Cups Paper Plates & Cups Metal Lan coultry to prevent overcooking. Arcing of if foil is too close to oven wall or door and damade oven will result. Browning dishes oven wall or door and damade contributed on the sign of the seign of the seign of the surface of the foil is too close to oven wall or door introduce only if labeled. Browning dishes are designed for microwave consting for instruction and heating chart. Do not preheating in the seign of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Paper Plates & Cups Sherica Arcing Arcing developed only if labeled only if labeled on the warm cooked foods, and to cook foods it short cooking times such as hot dogs. Lise to warm cooked foods, and to cook foods it short cooking times such as hot dogs.	
Browning Dish Brown paper bags No May cause a fire in the oven. Check manufacturers' use and care directions for instruction for instruction and heating chart. Do not preheat for more than May cause a fire in the oven. Check manufacturers' use and care directions for microwave heating. Some dinnerware may state back of the dish, "Oven-Microwave Safe". Unlabeled Dinnerware Paperboard Dishes Fast Food Carton with Metal Handle Frozen Dinner Tray Metal Frozen Dinner Tray Microwave safe Glass Jars No Metal can cause arcing and damage to your oven with glass and sandwiches only if labeled for warm rolls and sandwiches only if labeled for labeled provided, and sond sond sond sond sond sond sond so	can occur
Dinnerware: Labeled "Microwave Safe" Unlabeled Dinnerware Paper board Dishes Fast Food Carton with Metal Handle Frozen Dinner Tray Microwave safe Glass Jars Heat Resistant Oven Glassware & Ceramics Metal Bakeware Metal Twist-Ties No Metal Twist-Ties No Paper Plates & Cups Paper Plates & Cups Prosen Dinner Safe Ne Check manufacturers' use and care directions for microwave heating. Some dinnerware may stat back of the dish, "Oven-Microwave Safe". Use CONTAINER TEST below. Some frozen foods are packaged in these disher purchased in grocery stores. Fast Food Carton with Metal Handle No Metal handle may cause arcing. Metal can cause arcing and damage to your over cooking or reheating. Heat only 1 tray in the oven at one time. Most glass jars are not heat resistant. Do not use cooking or reheating. Ideal for microwave cooking and browning. (See CONTAINER TEST below) Not recommended for use in microwave ovens. cause arcing and damage to your oven. Metal Twist-Ties No May cause arcing which could cause a fire in the follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Ves Use to warm rolls and sandwiches only if labelet is provided and sandwiches only if labelet is provided and sandwiches only if labelet is provided. Its to warm rolls and sandwiches only if labelet is provided and sandwiches only if labelet is provided.	ctions
Labeled "Microwave Safe" Unlabeled Dinnerware Paperboard Dishes Fast Food Carton with Metal Handle Frozen Dinner Tray Microwave Safe Glass Jars Heat Resistant Oven Glassware & Ceramics Metal Twist-Ties No Metal Twist-Ties Paper Plates & Cups Pisposable polyester Paper Bank (Microwave Safe) Pyes Microwave heating. Some dinnerware may stat back of the dish, "Oven-Microwave Safe". Use CONTAINER TEST below. Some frozen foods are packaged in these disher purchased in grocery stores. Metal handle may cause arcing. Metal handle may cause arcing and damage to your oven. Metal can cause arcing and damage to your oven. Most glass jars are not heat resistant. Do not us cooking or reheating. Ideal for microwave cooking and browning. (See CONTAINER TEST below) Not recommended for use in microwave ovens. cause arcing and damage to your oven. May cause arcing and damage to your oven. May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with the provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Microwave Safe No Metal can cause arcing and damage to your oven. Most glass jars are not heat resistant. Do not us cooking or reheating. No Ideal for microwave cooking and browning. (See CONTAINER TEST below) Not recommended for use in microwave ovens. cause arcing and damage to your oven. May cause arcing and cause a fire in the follow manufacturers' directions. Close bag with the provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Yes Microwave Safe No Metal Can cause arcing and damage to your oven. Most glass jars are not heat resistant. Do not use cooking or reheating. Use to warm rolls and sandwiches only if labeled the page of the provided of the page of the	
Disposable polyester Paperboard Dishes Past Food Carton with Metal Handle Prozen Dinner Tray Metal Prozen Dinner Tray Microwave safe Glass Jars Heat Resistant Oven Glassware & Ceramics Metal Bakeware Metal Twist-Ties No Metal Twist-Ties Paper Plates & Cups Prozen Dinner Tray No Metal Rose Food Carton Wetal handle may cause arcing. Metal handle may cause arcing and damage to your over over over over over over over ove	
Paperboard Dishes Fast Food Carton with Metal Handle Frozen Dinner Tray Metal Frozen Dinner Tray Microwave safe Glass Jars Heat Resistant Oven Glassware & Ceramics Metal Bakeware Metal Twist-Ties No Metal Twist-Ties Paper Plates & Cups Paper Plates & Cups No Metal Inandle may cause arcing. Metal handle may cause arcing. Metal handle may cause arcing and damage to your over. Metal can cause arcing and damage to your over. Most glass jars are not heat resistant. Do not us cooking or reheating. Ideal for microwave cooking and browning. (See CONTAINER TEST below) Not recommended for use in microwave ovens. cause arcing and damage to your oven. May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Use to warm rolls and sandwiches only if labelet in the poor of cotton string. Do not close with metal twist-ties and sandwiches only if labelet poor only if labelet pages.	
Fast Food Carton with Metal Handle Frozen Dinner Tray Metal Frozen Dinner Tray Metal Frozen Dinner Tray Microwave safe Glass Jars Heat Resistant Oven Glassware & Ceramics Metal Bakeware No Metal Twist-Ties No No trecommended for use in microwave ovens. cause arcing and damage to your oven. Metal Twist-Ties No Metal Can cause arcing and damage to your oven in microwave ovens. cause arcing and damage to your oven. Metal Twist-Ties No Metal Can Cause arcing and browning. No recommended for use in microwave ovens. cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with the provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie view of cotton string. Do not close with metal twist-tie view of cotton string. Do not close with metal twist-tie view of cotton string. Do not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string. No not close with metal twist-tie view of cotton string.	es. Can be
Metal Survey Microwave safe Frozen Dinner Tray Microwave safe Glass Jars No Heat Resistant Oven Glassware & Ceramics Mot I Twist-Ties No Metal Twist-Ties No Metal Twist-Ties No Metal Twist-Ties Paper Plates & Cups No Metal Can cause arcing and damage to your over theat resistant. Do not us cooking or reheating. Most glass jars are not heat resistant. Do not us cooking or reheating. Ideal for microwave cooking and browning. (See CONTAINER TEST below) Not recommended for use in microwave ovens. cause arcing and damage to your oven. May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with the provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tien to cooking times such as hot dogs. Lise to warm rolls and sandwiches only if labelet warm rolls and sandwiches o	
Microwave safe ' Yes Heat only 1 tray in the oven at one time. Glass Jars No Most glass jars are not heat resistant. Do not us cooking or reheating. Heat Resistant Oven Glassware & Ceramics Yes (See CONTAINER TEST below) Metal Bakeware No Not recommended for use in microwave ovens. cause arcing and damage to your oven. Metal Twist-Ties No May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Yes Use to warm rolls and sandwiches only if labelet	en.
Heat Resistant Oven Glassware & Ceramics Metal Bakeware No Metal Twist-Ties No Metal Twist-Ties No Metal Twist-Ties No Metal Twist-Ties No May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Yes Cooking or reheating. No Ideal for microwave cooking and browning. No recommended for use in microwave ovens. Cause arcing and damage to your oven. May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Use to warm cooked foods, and to cook foods the short cooking times such as hot dogs.	
Glassware & Ceramics Yes (See CONTAINER TEST below)	se for
No cause arcing and damage to your oven. Metal Twist-Ties No May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Yes Use to warm cooked foods, and to cook foods the short cooking times such as hot dogs. Lise to warm rolls and sandwiches, only if labelet in the sandwiches only in	
Metal Twist-Ties No May cause arcing which could cause a fire in the Follow manufacturers' directions. Close bag with tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Paper Plates & Cups Yes Wes Yes Wes Lise to warm rolls and sandwiches, only if labelet to the provided of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Use to warm rolls and sandwiches, only if labelet to warm rolls and sandwiches.	Metal can
Oven Cooking Bag Yes tie provided, a strip cut from the end of the bag, of cotton string. Do not close with metal twist-tie 1/2-inch (1 cm) slits near the closure. Use to warm cooked foods, and to cook foods the short cooking times such as hot dogs. Use to warm rolls and sandwiches, only if labelet to warm rolls and sandwiches.	e oven.
Paper Plates & Cups Yes short cooking times such as hot dogs.	or a piece e. Make six
Use to warm rolls and sandwiches, only if labele	
Paper Towels & Napkins Yes microwave use.	ed safe for
Recycled Paper Towels & Napkins Recycled paper products may contain impurities cause sparks.	s which may
Parchment Paper Yes Use as a cover to prevent spattering. Safe for user increased in the prevent spattering. Safe for user increased in the prevent spattering in the preven	
Plastic: Microwave Safe Cookware Yes, use caution Should be labeled, "Suitable for Microwave Hea manufacturers' directions for recommended use Some microwave safe plastic containers are not cooking foods with high fat or sugar content. Th hot food may cause the plastic to warp.	ating." Check es. t suitable for
Plastic, Melamine No This material absorbs microwave energy. Disher	
Plastic Foam Cups Yes, use caution Yes, to reheat foods to a low serving temperature on	ly.
Plastic Wrap Yes Use to cover food during cooking to retain moist prevent spattering. Should be labeled "Suitable Microwave Heating". Check package directions.	for
Straw, Wicker, Wood Yes, use caution Yes, use caution Use only for short term reheating and to bring for serving temperature. Wood may dry out & split when used.	or crack
Thermometers- Microwave safe Yes Use only microwave safe meat and candy therm	nometers.
Thermometers- Conventional No Not suitable for use in microwave oven, will cau and get hot.	·
Wax paper Yes Use as a cover to prevent spattering and to reta	ain moisture.

CONTAINER TEST

TO TEST A CONTAINER FOR SAFE MICROWAVE OVEN USE: Fill a microwave safe cup with cool water and place it in the microwave oven alongside the empty container to be tested; heat one (1) minute at P10 (HIGH). If the container is microwave oven safe (transparent to microwave energy), the empty container should remain comfortably cool and the water should be hot. If the container is hot, it has absorbed some microwave energy and should NOT be used. This test cannot be used for plastic containers.


Oven Components Diagram



- a External Air Vent
- **(b)** Internal Air Vent
- © Door Safety Lock System
- **@** Exhaust Air Vent
- (e) Control Panel
- f Identification Plate
- **9** Glass Tray

- **(h)** Roller Ring
- (i) Heat/Vapor Barrier Film (do not remove)
- (i) Waveguide Cover (do not remove)
- **(k)** Door Release Button
- ① Menu Label

Control Panel



Beep Sound:

When a pad is pressed correctly, a beep will be heard.

If a pad is pressed and no beep is heard, the unit did not or cannot accept the instruction. When operating, the oven will beep twice between programmed stages. At the end of any complete program, the oven will beep 5 times.





- Plug into a properly grounded electrical outlet.
- "WELCOME TO PANASONIC..." message scrolls across display window.



Setting the Clock

Example: To set 11:25 a.m. or p.m.

1. Clock	• Press Clock once. ➤ Colon flashes.
2. 1 1 2 5	Enter time of day using the number pads. Time appears in the display window; colon continues flashing.
3. Clock	Press Clock. Colon stops flashing; time of day is entered.

NOTES:

- 1. To reset the clock, repeat step 1-3.
- The clock will retain the time of day as long as the oven is plugged in and electricity is supplied.
- 3. Clock is a 12 hour display.
- 4. Oven will not operate while colon is flashing.



Function Features

This unique function of your PANASONIC microwave oven allows you to establish the initial non-cooking features of your oven such as CHILD LOCK, WORD SPEED, LANGUAGE CHOICE (ENGLISH, FRENCH OR SPANISH), plus many more. See next page.

Function	Press Function.
2. O to 9 Press	Press selection by number pad (see chart on next page).
3. 1 to 3 Press	 Press selection by number pad (see chart on next page).

4. If other options are desired, repeat steps 1-3 for additional selections.



Function Features

(continued)



	(**************************************
→ 1 LANG	GUAGE CHOICE
¬ ∣ The o	ven has a choice of English, French or Spanish display. The
	y appears in English when you plug-in.
	ANCAIS Display appears in French.
3 ESF	1 7 11 1
	G CHOICE
The o	ven has both imperial and metric weight measurements. The
	displays the weight in imperial when you plug it in.
→*1 LB	→ Weight can be set in oz/lb, (Imperial).
2 KG	→ Weight can be set in g/kg, (Metric).
	D SPEED
	peed of word scrolling on the Display Window can be sped up
	wed down.
→ 1 QUI	
3 SLC	DIUM Scrolling speed returns to initial setting.
	,
	J ACTION ON/OFF
IVIEIVU	J ACTION SCREEN helps you to program your oven by oting the next step to be taken. When you become familiar
with w	our oven, the prompt can be turned off.
→*1 ON	
2 OFF	→ Prompting Guide will not appear.
	D LOCK ON/OFF
	ven has a Child Safety Lock feature which prevents use by
	en. It does not lock the door.
→ 1 ON	
	be accepted.
→*2 OFF	
→ 6 BEEF	ON/OFF
	wish to have the oven operate with no beep, it can be
elimin	
→*1 ON	→ Beep sound will reactivate.
→ 2 OFF	
→ 7 REMI	NDER BEEP ON/OFF
A rem	inder beep works to remind you to remove the food from the
	after the completion of cooking. It will occur every 15 seconds.
→ 1 ON	→ Reminder beep will work.
*2 OFF	→ Reminder beep will not work.
→ 8 DAYL	IGHT SAVING ON/OFF
—➤ 1 ON	
*2 OFF	
→ 9 CLOC	CK ON/OFF
	display can be turned off.
→*1 ON	→ Clock display will appear on the Display Window.
2 OFF	1 , 11
	Window.
	of day will be stored in memory while the display is off.
	O MODE ON/OFF
Demo	mode is designed for retail store display. In this mode, the
	can be demonstrated with no power in the oven.
→ 1 ON	→ The oven is in Demo mode.
*2 OFF	→ The oven is not in Demo mode.

^{*} DEFAULT MODE



Example: To cook at P 6 (MEDIUM)
power for 1 minute 30 seconds

Power Level (10 Levels) Press 5 times.	Press Power Level until the desired power level appears in the display window.
2.	Set Cooking Time using number pads.
3.	Press Start. ➤Cooking will start. The time in the display window will count down.

Press	Power Level
once	P10 (HIGH)
twice	P9
3 times	P8
4 times	P7 (MED-HIGH)
5 times	P6 (MEDIUM)
6 times	P5
7 times	P4
8 times	P3 (MED-LOW)/DEFROST
9 times	P2
10 times	P1 (LOW)

NOTES:

- For more than one stage cooking, repeat steps 1 and 2 for each stage of cooking before pressing *Start* Pad. The maximum number of stages for cooking is 5. When operating, two beeps will sound between each stage. Five beeps will sound at the end of the entire sequence.
- 2. When selecting P10 (HIGH) power for the first stage, you may begin at step 2.
- When selecting P10 (HIGH) power, the maximum programmable time is 30 minutes. For other power levels, the maximum time is 99 minutes and 99 seconds.
- For reheating, use P10 (HIGH) for liquids, P7 (MED-HIGH) for most foods and P6 (MEDIUM) for dense foods.
- 5. For defrosting, use P3 (MED-LOW).

DO NOT OVER COOK. This oven requires less time to cook than an older unit. Over cooking will cause food to dry out and may cause a fire. A microwave oven's cooking power tells you the amount of microwave power available for cooking.

Automatic features are provided for your convenience. If results are not suitable to your individual preference or if serving size is other than what is listed on page 17, please refer to manual cooking.



Quick Min Feature

This feature allows you to set or add cooking time in 1 minute increments up to 10 minutes.

To Set Cooking Time:

1. Quick Min	 Press Quick Min until the desired cooking time (up to 10 min- utes) appears in the display window. Power Level is pre-set at P10.
2. Start	Press <i>Start</i> . Cooking begins and the time will count down. At the end of cooking, 5 beeps sound.

NOTES:

- If desired, you can use other power levels. Select desired power level before setting cooking time.
- 2. After setting the time by **Quick Min** Pad, you cannot use Number Pads.
- Quick Min Pad can be used to add more time during manual cooking.



Keep Warm Feature

This feature will keep food warm for up to 30 minutes after cooking.

Example: To keep 2 cups of gravy warm

1. Keep Warm	• Press Keep Warm .
2. 0 to 9	Set warming time, up to 30 minutes.
3.	Press Start. ➤ Keep Warm will start. The time in the display window will count down.

NOTE:

Keep Warm can be programmed as the final stage after cook time/s have been manually entered. It cannot be used in combination with sensor or auto features.



Popcorn Feature

ample: To non 3.5 oz. of noncor

Example: To pop	3.5 oz. ot popcorn	
Рорсотп	Press Popcorn until the desired size appears in the display window. Press Weight once 3.5 oz (99 g) twice 3.0 oz (85 g) 3 times 1.75 oz (50 g)	
More/ Less Optional	• (see More/Less Feature.)	
3.	Press Start. ➤ After several seconds, cooking time appears in the display window and begins to count down.	

NOTES ON POPCORN FEATURE:

- 1. Pop one bag at a time.
- 2. Place bag in oven according to manufacturers' directions.
- 3. Start with popcorn at room temperature.
- Allow popped corn to sit unopened for a few minutes.
- Open bag carefully to prevent burns, because steam will escape.
- 6. Do not reheat unpopped kernels or reuse bag.

NOTE:

If popcorn is of a different weight than listed, follow instructions on popcorn package. Never leave the oven unattended. If popping slows to 2 to 3 seconds between pops, stop oven. Overcooking can cause fire.

REMARKS:

When popping multiple bags one right after the other, the cooking times may vary slightly. This does not affect the popcorn results.



More/Less Feature

For Popcorn:

By using the More/Less Pad, the programs can be adjusted to cook popcorn for a longer or shorter time if desired.

- 1 tap = Adds Approx. 10 secs.
- 2 taps = Adds Approx. 20 secs.
- 3 taps = Subtracts Approx. 10 secs.
- 4 taps = Subtracts Approx. 20 secs.
- 5 taps = original setting

Press More/Less pad before pressing Start.

For Sensor Reheat/Cook:

Preferences for food doneness vary with each individual. After having used the Sensor Reheat/Cook feature a few times. you may decide you would prefer your food cooked to a different doneness.

- 1 tap = More (Adds Approx. 10% time)
- 2 taps = Less (Subtracts Approx. 10% time)
- 3 taps = original setting

Press More/Less pad before pressing Start.



Inverter Turbo Defrost Feature

This feature allows you to defrost foods such as: meat, poultry and seafood simply by entering the weight.

Example: To defrost 1.5 pounds of meat

Place food on microwave safe dish

Inverter Turbo Defrost	Press Inverter Turbo Defrost.
2.	Enter weight of the food using the num- ber pads.
3.	Press Start. Defrosting will start. The time will count down. Larger weight foods will cause a signal midway through defrosting. If 2 beeps sound, turn over, rearrange foods or shield with aluminum foil.

Conversion Chart:

Follow the chart to convert ounces or hundredths of a pound into tenths of a pound. To use Inverter Turbo Defrost, enter the weight of the food in lbs. (1.0) and tenths of a lb. (0.1). If a piece of meat weighs 1.95 lbs. or 1 lb. 14 oz.. enter 1.9 lbs

Ounces	Hundredths of a Pound	Tenths of a Pound
0	.0105	0.0
1 - 2	.0615	0.1
3 - 4	.1625	0.2
5	.2635	0.3
6 - 7	.3645	0.4
8	.4655	0.5
9 - 10	.5665	0.6
11 - 12	.6675	0.7
13	.7685	0.8
14 - 15	.8695	0.9



' Defrosting Tips & Techniques

Preparation For Freezing:

- 1. Freeze meats, poultry, and fish in packages with only 1 or 2 layers of food. Place wax paper between layers.
- 2. Package in heavy-duty plastic wraps, bags (labeled "For Freezer"), or freezer paper.
- 3. Remove as much air as possible.
- 4. Seal securely, date, and label.

To Defrost:

- 1. Remove wrapper. This helps moisture to evaporate. Juices from food can get hot and cook the food.
- 2. Set food in microwave safe dish.
- 3. Place roasts fat-side down. Place whole poultry breast-side down.
- 4. Select power and minimum time so that items will be under-defrosted.
- 5. Drain liquids during defrosting.
- 6. Turn over (invert) items during defrosting.
- 7. Shield edges and ends if needed. (See Cooking Techniques).

After Defrosting:

- 1. Large items may be icy in the center. Defrosting will complete during STANDING TIME.
- 2. Let stand, covered, following stand time directions on page 15.
- 3. Rinse foods indicated in the chart.
- 4. Items which have been layered should be rinsed separately or have a longer stand time.



Defrosting Tips & Techniques (continued)

FOOD	DEFROST TIME at P3	DURING DEFROSTING	AFTER DEFF	ROSTING
1005	mins (per lb)		Stand Time	Rinse
Fish and Seafood [up to 3 lbs. (1.4 kg)] Crabmeat Fish Steaks	6 4 to 6	Break apart/Rearrange	E main	VEO
Fish Fillets Sea Scallops Whole fish	4 to 6 4 to 6 4 to 6	Turn over/Rearrange/Shield ends Break apart/Remove defrosted pieces Turn over	5 min.	YES
Meat Ground Meat	4 to 5	Turn over/Remove defrosted portion/Shield edges	10 min.	
Roasts [21/2-4 lbs. (1.1-1.8 kg)]	4 to 8	Turn over/Shield ends and defrosted surface	30 min. in refrig.	
Chops/Steak	6 to 8	Turn over/Rearrange/Shield ends and defrosted surface		
Ribs/T-bone	6 to 8	Turn over/Rearrange/Shield ends and defrosted surface	5 min.	NO
Stew Meat	4 to 8	Break apart/Rearrange/ Remove defrosted pieces	3 111111.	NO
Liver (thinly sliced)	4 to 6	Drain liquid/Turn over/ Separate pieces		
Bacon (sliced)	4	Turn over		
Poultry Chicken, Whole [up to 3 lbs. (1.4 kg)]	4 to 6	Turn over/Shield	20 min. in refrig.	
Cutlets	4 to 6	Break apart/Turn over/ Remove defrosted Pieces	5 min.	YES
Pieces	4 to 6	Break apart/Turn over/Shield	10 min.	120
Cornish Hens	6 to 8	Turn over/Shield	10 111111.	
Turkey Breast [5-6 lbs. (2.3-2.7 kg)]	6	Turn over/Shield	20 min. in refrig.	



Sensor Reheat Feature

This sensor feature allows you to reheat cooked, refrigerated food without setting time. The oven simplifies programming.

Example: To reheat a plate of food

	•
Sensor Reheat	• Press Sensor Reheat.
2. More/ Less Optional	• (see More/Less Feature) (• page 13)
3. Start	• Press <i>Start</i> . ➤ Cooking starts.

Cooking is complete when 5 beeps sound. (When steam is detected by the Genius Sensor and 2 beeps sound, the remaining cooking time will appear in the display window.)

NOTE:

Casseroles - Add 3 to 4 tablespoons of liquid, cover with lid or vented plastic wrap. Stir when time appears in the display window.

Canned foods - Empty contents into casserole dish or serving bowl, cover dish with lid or vented plastic wrap. After reheating, let stand for a few minutes.

Plate of food - Arrange food on plate; top with butter, gravy, etc. Cover with lid or vented plastic wrap. After reheating, let stand for a few minutes.

DO NOT USE SENSOR REHEAT:

- To reheat bread and pastry products. Use manual power and time for these foods.
- 2. For raw or uncooked foods.
- 3. If oven cavity is warm.
- 4. For beverages.
- 5. For frozen foods.



Sensor Cook Feature

This sensor feature allows you to cook food without setting time. The oven simplifies programming.

Example: To cook Frozen Entrées

1. Sensor Cook Press 4 times	 Press until the desired food appears on the display window.
2. More/ Less Optional	• (see More/Less Feature) (• page 13)
3. Start	• Press <i>Start</i> . ➤ Cooking starts.

Cooking is complete when 5 beeps sound. (When steam is detected by the Genius Sensor and 2 beeps sound, the remaining cooking time will appear in the display window.)

For the best results with the *GENIUS SENSOR*, follow these recommendations.

BEFORE Reheating/Cooking:

- 1. The room temperature surrounding the oven should be below 95° F (35° C).
- 2. Food weight should exceed 4 oz. (110 g).
- Be sure the glass tray, the outside of the cooking containers and the inside of the microwave oven are dry before placing food in the oven. Residual beads of moisture turning into steam can mislead the sensor.
- Cover food with lid, or with vented plastic wrap. Never use tightly sealed plastic containers—they can prevent steam from escaping and cause food to overcook.

DURING Reheating/Cooking:

DO NOT open the oven door until 2 beeps sound and cooking time appears on the Display Window. Doing so will cause inaccurate cooking since the steam from food is no longer contained within the oven cavity. Once the cooking time begins to count down, the oven door may be opened to stir, turn, or rearrange foods.

AFTER Reheating/Cooking:

All foods should have a stand time.



Sensor Cook Chart

Recipe	Serving/Weight	Hints	
1. Oatmeal	½ - 1 cup (40 - 80 g)	Place inside a microwave safe serving bowl with no cover. Follow manufacturers' directions for preparation.	
2. Breakfast Sausage	2 - 8 links	Follow manufacturers' directions for preparation of pre-cooked breakfast sausage. Place in a radial pattern.	
3. Omelet	2, 4 eggs	Follow Basic Omelet recipe on page 18.	
4. Frozen Entrées	8 - 32 oz. (225 - 900 g)	Follow manufacturers' directions for preparation. After 2 beeps, stir or rearrange. Be careful when removing the film cover after cooking. Remove facing away from you to avoid steam burns. If additional time is needed, continue to cook manually.	
5. Frozen Pizza (single)	8 oz. (225 g)	Follow manufacturers' directions for preparation.	
6. Potatoes	1 - 4 potatoes (6 - 8 oz. each) (170 - 225 g)	Pierce each potato with a fork 6 times spacing around surface. Place potato or potatoes around the edge of paper-towel-lined glass tray (Turntable), at least 1 inch (2.5 cm) apart. Do not cover. Let stand 5 minutes to complete cooking.	
7. Fresh Vegetables	4 - 16 oz. (110 - 450 g)	All pieces should be the same size. Wash thoroughly, add 1 tbsp. of water per 1/2 cup of vegetables, and cover with lid or vented plastic wrap. Do not salt/butter until after cooking.	
8. Frozen Vegetables	6 - 16 oz. (170- 450 g)	Wash thoroughly, add 1 tbsp. of water per ½ cup of vegetables, and cover with lid or vented plastic wrap. Do not salt/butter until after cooking. (Not suitable for vegetables in butter or sauce.) After 2 beeps, stir or rearrange.	
9. Pasta	2 - 8 oz. (56 - 225 g)	Place pasta with hot tap water in a microwave safe casserole dish. Cover with lid or vented plastic wrap.	



Microwave Recipes

OMELET

Basic Omelet

tablespoon butter or margarine

2 eggs

2 tablespoons milk salt and ground black pepper, if desired

Heat butter in a microwave safe 9-inch pie plate, 20 seconds at P10, or until melted. Turn the plate to coat the bottom with butter. Meanwhile, combine the remaining ingredients in a separate bowl, beat together and pour into the pie plate.

Cook, covered with vented plastic wrap, using OMELET selection. Let stand 2 minutes. With a spatula, loosen the edges of the omelet from the plate, fold into thirds to serve. Always use scrambled eggs.

Yield: 1 serving

Approx. cooking time: 4 minutes. **NOTE:** Double ingredients for a 4 egg

Omelet.

CASSEROLE

Shepherd's Pie

1 pound lean ground beef 1/2 cup frozen peas, thawed

1/4 cup chopped onion

1 tablespoon gravy powder 1/2 teaspoon curry powder

1/4 teaspoon salt

1/4 teaspoon ground black pepper

2 cups mashed potatoes

In a 2-Qt. casserole dish, crumble the ground beef and cook for 5-7 minutes at P6 or until the meat is cooked, stirring twice. Add the remaining ingredients, except for potatoes. Stir well, and then spread the potatoes evenly on the top. Cover with a lid or vented plastic wrap and cook at P6 power for 16-18 minutes.

Yield: 4 servings

Macaroni and Cheese

1/4 cup butter

2 tablespoons chopped onion

1 clove minced garlic

1/4 cup all-purpose flour

1 teaspoon dry mustard

1 teaspoon salt

1/4 teaspoon ground black pepper

2 cups milk

2 cups grated cheddar cheese

8 oz. (1/2 lb dry weight) macaroni, cooked and drained

1/3 cup bread crumbs

1 teaspoon paprika

In a 2-Qt. casserole, melt the butter for 40 seconds at P10. Add onion and garlic and cook for 1 minute at P10. Stir in flour, mustard, salt and pepper, and gradually add the milk. Cook for 3-4 minutes at P10 until sauce thickens, stirring once. Add the cheddar cheese, stirring thoroughly. Pour and stir the sauce into the macaroni, in a 3-Qt. casserole. Top with bread crumbs and paprika. Cover with lid or vented plastic wrap. Cook at P6 power for 16-18 minutes.

Yield: 6 servings

Beef and Macaroni Casserole

pound lean ground beef

small onion, chopped green bell pepper, chopped

1 cup chopped celery

2 15 oz. cans tomato sauce

11/4 cups water

1 cup uncooked elbow macaroni

teaspoon parsleyteaspoon salt

1/4 teaspoon ground black pepper

1/2 cup grated cheddar cheese

Crumble the ground beef in a 3-Qt. casserole. Cook for 5-7 minutes at P6 or until the meat is cooked, stirring twice. Stir in onion, peppers and celery. Cook for 3-4 minutes at P10. Stir in the remaining ingredients, except cheese. Cover with lid or vented plastic wrap. Cook at P6 power for 16-18 minutes. Sprinkle with cheese. Cover and let stand 5 minutes.

Yield: 4-6 servings

Tuna Casserole

6 oz. can tuna, drained and flakedcups cooked and drained noodles

1 10³/₄ oz. can condensed cream of

mushroom soup

4 oz. can mushroom pieces and stems,
drained

1 16 oz. package frozen peas, defrosted

³/₄ cup milk

1 cup crushed potato chips

1/2 cup grated cheddar cheese

In a 3-Qt. casserole, combine tuna, noodles, soup, mushrooms, peas and milk; mix well. Cover with lid or vented plastic wrap. Cook at P6 power for 16-18 minutes. Top with potato chips and cheese before serving.

Yield: 4-6 servings



Timer Feature

This feature allows you to program the oven as a kitchen timer. It can also be used to program a standing time after cooking is completed and/or to program a delay start.

To Use as a Kitchen Timer:

Example: To count down 5 minutes.		
1. Timer	• Press Timer .	
2. 5 0 0	Set desired amount of time using number pads. (up to 99 minutes and 99 seconds).	
3. Start	Press Start. Time will count down without oven operating.	

To Set Stand Time:

Example: To cook at P6 power for 3 minutes, with stand time of 5 minutes

5 minutes.	
Power Level (10 Levels) Press 5 times	Enter the desired Power Level (see page 12 for directions).
2.	Set desired cooking time using number pads.
3. Timer	• Press Timer .
5 0 0	• Set desired amount of Stand Time using number pads. (up to 99 minutes and 99 seconds)
5.	Press Start. Cooking will start. After cooking, stand time will count down without oven operating.

CAUTION:

If oven lamp is lit while using the timer feature, the oven is incorrectly programed. Stop oven immediately and re-read instructions.

To Set Delay Start:

Example: To delay the start of cooking for 5 minutes, and cook at P6 power for 3 minutes.

1. Timer	• Press Timer .
5 0 0	Enter desired amount of delay time using number pads. (up to 99 minutes and 99 seconds)
Power Level (10 Levels) Press 5 times	Enter the desired Power Level (see page 12 for directions).
4. 3 0 0	Set desired cooking time using number pads.
5. Start	Press <i>Start</i> . ➤ Delay time will count down. Then cooking will start.

NOTE:

- When each stage finishes, a two-beep signal sounds. At the end of the program, the oven will beep five times.
- If the oven door is opened during Stand Time, Kitchen Timer or Delay Time, the time on the display will continue to count down.
- Stand time and Delay start cannot be programmed before any automatic Function. This is to prevent the starting temperature of food from rising before defrosting or cooking begins. A change in starting temperature could cause inaccurate results.



Microwave Shortcuts

FOOD	POWER	TIME (in mins.)	DIRECTIONS
To separate refrigerated Bacon , 1 pound (450 g)	P10 (HIGH)	30 sec.	Remove wrapper and place in microwave safe dish. After heating, use a plastic spatula to separate slices.
To soften Brown Sugar 1 cup (250 ml)	P10 (HIGH)	20 - 30 sec.	Place brown sugar in microwave safe dish with a slice of bread. Cover with lid or plastic wrap.
To soften refrigerated Butter , 1 stick, ¹ / ₄ pound (110 g)	P3 (MED-LOW)	1	Remove wrapper and place butter in a microwave safe dish.
To melt refrigerated Butter , 1 stick, ¹ / ₄ pound (110 g)	P6 (MEDIUM)	11/2 - 2	Remove wrapper and place butter in a microwave safe dish covered with lid or vented plastic wrap.
To melt Chocolate , 1 square, 1 oz. (28 g) To melt Chocolate , 1/2 cup (125 ml) chips	P6 (MEDIUM) P6 (MEDIUM)	1 - 1 ¹ / ₂ 1 - 1 ¹ / ₂	Remove wrapper and place chocolate in a microwave safe dish. After heating, stir until completely melted. Note: Chocolate holds its shape even when softened.
To toast Coconut , 1/2 cup (125 ml)	P10 (HIGH)	1	Place in a microwave safe dish. Stir every 30 seconds.
To soften Cream Cheese , 8 oz. (225 g)	P3 (MED-LOW)	1 - 2	Remove wrapper and place in a microwave safe bowl.
To brown Ground Beef , 1 pound (450 g)	P10 (HIGH)	4 - 5	Crumble into a microwave safe colander set into another dish. Cover with plastic wrap. Stir twice. Drain grease.
To cook Vegetables , Fresh (1/2 lb) (225 g)	P8	31/2 - 4	All pieces should be the same size. Wash thoroughly, add 1 tbsp of water per ½ cup of vegetables, and cover with lid or vented plastic wrap. Do not salt/butter until after cooking.
Frozen (10 oz) (285 g)	P8	31/2 - 4	Wash thoroughly, add 1 tbsp of water per ½ cup of vegetables, and cover with lid or vented plastic wrap. Do not salt/butter until after cooking. (Not suitable for vegetables in butter or sauce.)
Canned (15 oz) (430 g)	P8	31/2 - 4	Empty contents into microwave safe serving bowl. Do not cover.



Microwave Shortcuts

(continued)

FOOD	POWER	TIME (in mins.)	DIRECTIONS
To cook baked Potato , (6 - 8 oz. each) (170 - 225 g)		211	Pierce each potato with a fork 6 times spacing around surface. Place potato or potatoes around the edge of paper-towel-
2	P8 P8	3¹/₂ - 4 6 - 7	lined glass tray (Turntable), at least 1 inch (2.5 cm) apart. Do not cover. Let stand 5 minutes to complete cooking.
To steam Hand Towels - 4	P10 (HIGH)	20 - 30 sec.	Soak in water, then wring out excess. Place on a microwave safe dish. Heat. Present immediately.
To soften Ice Cream , ¹ / ₂ gallon (2 L)	P3 (MED-LOW)	1 - 11/2	Check often to prevent melting.
Cup of liquid To boil water, broth, etc. 1 cup, 8 oz. (250 ml) 2 cups, 16 oz. (500 ml)	P10 (HIGH) P10 (HIGH)	1 ¹ / ₂ - 2 2 ¹ / ₂ - 3	Heated liquids can erupt if not stirred. Do not heat liquids in microwave oven
Cup of liquid To warm Beverage, 1 cup, 8 oz. (250 ml) 2 cups, 16 oz. (500 ml)	P7 (MED-HIGH) P7 (MED-HIGH)		without stirring before heating.
To roast Nuts , 1½ cups (375 ml)	P10 (HIGH)	3 - 4	Spread nuts into a 9-inch (23 cm) microwave safe pie plate. Stir occasionally.
To toast Sesame Seeds , ¹ / ₄ cup (60 ml)	P10 (HIGH)	2 - 21/2	Place in a small microwave safe bowl. Stir twice.
To skin Tomatoes , (one at a time)	P10 (HIGH)	30 sec.	Place tomato into a microwave safe bowl containing boiling water. Rinse and peel. Repeat for each tomato.
To remove Cooking Odors ,	P10 (HIGH)	5	Combine 1 to 11/2 cups (250 - 375 ml) water with the juice and peel of one lemon in a 2 quart microwave safe bowl. After water finishes boiling, wipe interior of oven with a cloth.


Food Characteristics

Bone and Fat

Both bone and fat affect cooking. Bones may cause irregular cooking. Meat next to the tips of bones may overcook while meat positioned under a large bone, such as a ham bone, may be undercooked. Large amounts of fat absorb microwave energy and the meat next to these areas may overcook.

Density

Porous, airy foods such as breads, cakes or rolls take less time to cook than heavy, dense foods such as potatoes and roasts. When reheating donuts or other



Quantity

Two potatoes take longer to cook than one potato. As the quantity of the food decreases so does the cooking time. Overcooking will cause the moisture content in the food to decrease and a fire could result. Never leave microwave unattended while in use.

Shape

Uniform sizes heat more evenly. The thin end of a drumstick will cook more quickly than the meaty



end. To compensate for irregular shapes, place thin parts toward the center of the dish and thick pieces toward the edge.

Size

Thin pieces cook more quickly than thick pieces.



Starting Temperature

Foods that are at room temperature take less time to cook than if they are chilled, refrigerated, or frozen.



Cooking Techniques

Piercing


Foods with skins or membranes must be pierced scored or have a strip of skin peeled before cooking to allow steam to escape. Pierce clams,



oysters, chicken livers, whole potatoes and whole vegetables. Whole apples or new potatoes should have a 1-inch strip of skin peeled before cooking. Score sausages and frankfurters. Do not Cook/Reheat whole eggs with or without the shell. Steam build up in whole eggs may cause them to explode, and possibly damage the oven or cause injury. Reheating SLICED hard-boiled eggs and cooking SCRAMBLED eggs is safe.

Browning

Foods will not have the same brown appearance as conventionally cooked foods or those foods which are cooked utilizing a browning feature. Meats and poultry



Spacing

Individual foods, such as baked potatoes, cupcakes and appetizers, will cook more evenly if placed in the oven equal distances apart. When possible, arrange foods in a circular pattern.



Cooking Techniques

(continued)

Covering

As with conventional cooking, moisture evaporates during microwave cooking. Casserole lids or plastic wrap are used for a tighter seal. When using plastic wrap, vent the plastic wrap by folding back part of the plastic wrap from the edge of the dish to allow steam to escape. Loosen or remove plastic wrap as recipe directs for stand time. When removing plastic wrap covers, as well as any glass lids, be careful to remove them away from you to avoid steam burns. Various degrees of moisture retention are also obtained by using wax paper or paper towels.

Shielding

Thin areas of meat and poultry cook more quickly than meaty portions. To prevent overcooking, these thin areas can be shielded with strips of aluminum foil. Wooden toothpicks may be used to hold the foil in place.

ACAUTION is to be exercised when using foil. Arcing can occur if foil is too close to oven wall or door and damage to your oven will result.

Cooking time

A range of cooking time is given in each recipe. The time range compensates for the uncontrollable differences in food shapes, starting temperature, and regional preferences. Always cook food for the minimum cooking time given in a recipe and check for doneness. If the food is undercooked, continue cooking. It is easier to add time to an undercooked product. Once the food is overcooked, nothing can be done.

Stirring

Stirring is usually necessary during microwave cooking. Always bring the cooked outside edges toward the center and the less cooked center portions toward the outside of the dish.

Rearranging

Rearrange small items such as chicken pieces, shrimp, hamburger patties, or pork chops. Rearrange pieces from the edge to the center and pieces from the center to the edge of the dish.

Turning

It is not possible to stir some foods to distribute the heat evenly. At times, microwave energy will concentrate in one area of the food. To help insure even cooking, these food need to be turned. Turn over large foods, such as roasts or turkeys, halfway through cooking.

Stand Time

Most foods will continue to cook by conduction after the microwave oven is turned off. In meat cookery, the internal temperature will rise 5°F to 15°F (3°C to 8°C), if allowed to stand, tented with foil, for 10 to 15 minutes. Casseroles and vegetables need a shorter amount of standing time, but this standing time is necessary to allow foods to complete cooking to the center without overcooking on the edges.

Test for Doneness

The same tests for doneness used in conventional cooking may be used for microwave cooking. Meat is done when fork-tender or splits at fibers. Chicken is done when juices are clear yellow and drumstick moves freely. Fish is done when it flakes and is opaque. Cake is done when a toothpick or cake tester is inserted and comes out clean.

ABOUT FOOD SAFETY AND COOKING TEMPERATURE

Check foods to see that they are cooked to the United States Department of Agriculture's recommended temperatures.

-	•
TEMP	FOOD
160°F	for fresh pork, ground meat, boneless white poultry, fish, seafood, egg dishes and frozen prepared food.
165°F	for leftover, ready-to-reheat refrigerated, and deli and carryout "fresh" food.
170°F	white meat of poultry.
180°F	dark meat of poultry.

To test for doneness, insert a meat thermometer in a thick or dense area away from fat or bone. NEVER leave the thermometer in the food during cooking, unless it is approved for microwave oven use.



Menu Label:

a damp cloth.

Care and Cleaning of Your Microwave Oven

AFTER CLEANING:

BEFORE CLEANING:

Unplug oven at wall outlet. If outlet is inaccessible. leave oven door open while cleaning.

f

Glass Trav:

Remove and wash in warm soapv water or in a dishwasher.

Outside oven surfaces:

Be sure to place the Roller Ring and the Glass

Tray in the proper position and press Stop/Reset Pad to clear the Display.

> Clean with a damp cloth. To prevent damage to the operating parts inside the oven, water should not be allowed to seep into ventilation openings.

Control Panel:

Covered with a removable protective film to prevent scratches during shipping. Small bubbles may appear under this film. (Hint - To remove film, apply masking or clear tape to an exposed corner and pull gently.)

* If the Control Panel becomes wet, clean it with a soft dry cloth. Do not use harsh detergents or abrasives.

Do not remove waveguide cover: It is important to keep cover clean in the same manner as the inside of the oven.

Inside of the oven: Wipe with a damp cloth after using. Mild detergent may be used if needed. Do not use harsh detergents or abrasives. Oven Door: Wipe with a soft dry

Do not remove, wipe with

cloth when steam accumulates inside or around the outside of the oven door. During cooking, especially under high humidity conditions, steam is given off from the food. (Some steam will condense on cooler surfaces, such as

the oven door. This is normal.) Inside surface is covered with a heat and vapor barrier film. Do not remove.

Roller Ring and oven cavity floor: Clean the bottom surface of the oven with mild detergent water or window cleaner, and dry. Roller Ring may be washed in mild soapy water or dishwasher. These areas should be kept clean to avoid excessive noise.

IT IS IMPORTANT TO KEEP THE OVEN CLEAN AND DRY. FOOD RESIDUE AND CONDENSATION MAY CAUSE RUSTING OR ARCING AND DAMAGE TO THE OVEN. AFTER USE, WIPE DRY ALL SURFACES-INCLUDING VENT OPENINGS, OVEN SEAMS, AND UNDER GLASS TRAY.

PARTS DESCRIPTION

Instructions / Operating Manual (this book)

Glass Tray

Roller Ring Assembly

PART NUMBER

F00037C51AP

F06014W00AP

(NN-H735/H765/SN776) (NN-H935/H965)

F06014M00AP

F290D9330AP

Accessory Purchases

Purchase Parts, Accessories and Instruction Books online for all Panasonic Products by visiting our Web Site at: http://www.pasc.panasonic.com

or, send your request by E-mail to: npcparts@us.panasonic.com

You may also contact us directly at:

1-800-332-5368 (Phone) 1-800-237-9080 (Fax Only) (Monday-Friday 9 am to 8 pm, EST.)

Panasonic Services Company

20421 84th Avenue South.

Kent, WA 98032

(We Accept Visa, MasterCard, Discover Card, American Express, and Personal Checks)

For hearing or speech impaired TTY users, TTY: 1-866-605-1277



Before Requesting Service

These things are normal:

The oven causes interference with my TV.

Some radio and TV interference might occur when you cook with the microwave oven. This interference is similar to the interference caused by small appliances such as mixers, vacuums, blow dryers, etc. It does not indicate a problem with your oven.

Steam accumulates on the oven door and warm air comes from the oven vents During cooking, steam and warm air are given off from the food. Most of the steam and warm air are removed from the oven by the air which circulates in the oven cavity. However, some steam will condense on cooler surfaces such as the oven door. This is normal. After use, the oven should be wiped dry (see page 24).

PROBLEM

POSSIBLE CAUSE

REMEDY

The oven is not plugged in Remove plug from outlet, wait 10 seconds and re-insert. securely. Circuit breaker or fuse is Reset circuit breaker or replace Oven will not turn on. tripped or blown. fuse. There is a problem with the Plug another appliance into the outlet. outlet to check if it is working. The door is not closed Close the oven door securely. completely. Start Pad was not pressed Press Start Pad. after programming. Another program is already Press **Stop/Reset** Pad to cancel Oven will not start entered into the oven. the previous program and enter cookina. new program. The program is not correct. Program again according to the Operating Instructions. Stop/Reset Pad has been Program oven again. pressed accidentally. The Glass Tray is not Take out Glass Tray and Roller positioned properly on the Ring. Wipe with a damp cloth and The Glass Trav wobbles. Roller Ring or there is food reset Roller Ring and Glass Tray under the Roller Ring. properly.

When the oven is operating, there is noise coming from the glass tray.

The Roller Ring and oven bottom are dirty.

Clean these parts according to Care and Cleaning of your Microwave Oven (see page 24).

The word "LOCK" appears in the **Display Window**.

The CHILD LOCK was See **Function** Pad on page 11. activated.

Limited Warranty & Customer Services Directory

PANASONIC CONSUMER ELECTRONICS COMPANY. DIVISION OF PANASONIC CORPORATION OF NORTH AMERICA One Panasonic Way Secaucus, New Jersey 07094

PANASONIC SALES COMPANY. DIVISION OF PANASONIC PUERTO RICO, INC Ave. 65 de Infanteria, Km. 9.5 San Gabriel Industrial Park Carolina, Puerto Rico 00985

Panasonic Microwave Oven Product **Limited Warranty**

Limited Warranty Coverage

If your product does not work properly because of a defect in materials or workmanship, Panasonic Consumer Electronics Company or Panasonic Sales Company (collectively referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

ALL PARTS (EXCEPT MAGNETRON TUBE) MAGNETRON TUBE

PARTS LABOR 1 (ONE) YEAR 5 (FIVE) YEAR 1 (ONE) YEAR 1 (ONE) YEAR

During the "Labor" warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must carry-in or mail-in your product during the warranty period. This warranty only applies to products purchased and serviced in the United States or Puerto Rico. This warranty is extended only to the original purchaser of a new product which was not sold "as is". A purchase receipt or other proof of the original purchase date is required for warranty service.

Carry-In or Mail-In Service

For Ćarry-In or Mail-In Service in the United States call 1-800-211-PANA(7262) or visit Panasonic Web Site: http://www.panasonic.com

For assistance in Puerto Rico call Panasonic Sales Company (787)-750-4300 or fax (787)-768-2910.

Limited Warranty Limits And Exclusions
This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER glass, plastic parts, temperature probes(if included) and normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, bug infestation, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, or commercial use (such as in a hotel, office, restaurant, or other business), rental use of the product, service by anyone other than a Factory Service center or other Authorized Servicer, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COV-

ERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WAR-RANTY. (As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, or travel to and from the servicer. The items listed are not exclusive, but are for illustration only.) ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MER-CHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on

how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have others rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Service center. If the problem is not handled to your satisfaction, then write to the warrantor's Consumer Affairs Department at the addresses listed for the warrantor.

PARTS AND SERVICE WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY ARE YOUR RESPONSIBILITY

Customer Services Directory

Obtain Product Information and Operating Assistance; locate your nearest Dealer or servicenter; purchase Parts and Accessories; or make Customer Service and Literature requests by visiting our Web Site at: http://www.panasonic.com/consumersupport

or, contact us via the web at: http://www.panasonic.com/contactinfo

You may also contact us directly at: 1-800-211-PANA(7262). Monday-Friday 9 am-9 pm; Saturday-Sunday 10 am-7 pm, EST.

For hearing or speech impaired TTY users, TTY: 1-877-833-8855

Service in Puerto Rico

Panasonic Puerto Rico. Inc.

Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park, Carolina, Puerto Rico 00985 Phone (787)750-4300. Fax (787)768-2910

QUICK GUIDE TO OPERATION

Feature	How to Operate
To set Clock	Clock → 0 Thru 9 → Clock
(p age 10)	Press once. Enter time of day. Press once.
To set Power and Time	Power Level (10 Levels) → 0 Thru 9 → Start
(p age 12)	Press to select Power Level. Set cooking time. Press.
To Use Function (•page 10)	Function ☐ Thru ☐ → ☐ or
To cook using Popcorn	Papern More/ Less Start
(☞ page 13)	Select weight. Optional. Press.
To cook using Quick Min	Quick Min Start
(page 12)	(up to 10 min.) Press.
To reheat using Sensor Reheat	Sensor Reheat → More/ Less → Start
(page 16)	Press once. Optional. Press.
To cook using Sensor Cook	e.g. Sensor More/ Less Start
(☞ page 16)	Select food. Optional. Press.
To defrost using Inverter Turbo Defrost	Inverter Turbo Defrost O Thru 9 → Start
(p age 14)	Press once. Set weight. Press.
To use Keep Warm (●page 12)	Warm Press once. Set keep warm time. (up to 30 min.) Press. Start Press.
To use as a Kitchen Timer	Timer → 0 Thru 9 → Start
(p age 19)	Press once. Set time. Press.
To Set Stand Time (page 19)	Input up to 4-stage cooking programs. Timer
To Set Delay Start (*page 19)	Timer O Thru O Thru



Specifications

	NN-H735/H765/SN776	NN-H935/H965	
Power Source:	120 V, 60 Hz		
Power Consumption:	12.7 Amps	s, 1,460 W	
Cooking Power:*	1,250 W		
Outside Dimensions	11 15/16" x 21 7/8" x 19 7/16"	14" x 23 ⁷ / ₈ " x 19 ⁷ / ₁₆ "	
(H x W x D):	(304 mm x 555 mm x 493 mm)	(356 mm x 606 mm x 493 mm)	
Oven Cavity Dimensions	9" x 16 ⁷ / ₁₆ " x 18 ¹ / ₂ "	10 ¹⁵ / ₁₆ " x 18 ⁷ / ₁₆ " x 18 ¹ / ₂ "	
(H x W x D):	(228 mm x 418 mm x 470 mm)	(278 mm x 469 mm x 470 mm)	
Operating Frequency:	2,450 MHz		
Net Weight:	Approx. 32 lbs (14.3 kg)	Approx. 37.5 lbs (17.0 kg)	
Trim Kit	NN-TK729SF		
(Outside dimension):	(Stainless microwave ovens only)		
(for SN776 only)	27" x 16 ¹ / ₂ "		
White and black	(685 mm x 419 mm)		
microwave ovens are not	NN-TK739SF	Net between the few body to the	
intended for built-in use.	(Stainless microwave ovens only)	Not intended for built-in use	
	30" x 16 ¹ / ₂ "		
	(762 mm x 419 mm)		
Trim Kit Cabinet Opening:	24 ⁷ / ₈ " x 15 ⁵ / ₁₆ " x 21"		
	(632 mm x 389 mm x 533.4 mm)		

*IEC Test procedure

Specifications subject to change without notice.

User's Record

The serial number of this product may be found on the back side of the oven. You should note the model number and the serial number of this oven in the space provided and retain this book as a permanent record of your purchase for future reference.

Model No	
Serial No	
Date of Purchase	

Panasonic Consumer Electronics Company, Division of Panasonic Corporation of North America One Panasonic Way Secaucus, New Jersey 07094 Panasonic Sales Company, Division of Panasonic Puerto Rico, Inc. ("PSC")

Ave. 65 de Infanteria, Km. 9.5 San Gabriel Industrial Park, Carolina, Puerto Rico 00985

Matsushita Electric Industrial Co., Ltd.

Panasonic Home Appliances Microwave Oven (Shanghai) Co., Ltd.

898 Long Dong Road, Pu Dong, Shanghai, China 201203


Web Site: http://www.panasonic.co.jp/global



Panasonic

Instrucciones de Operación Horno de Microondas

> Modelos: NN-H735/H765/H935/ H965/SN776



Información de Seguridad

Instrucciones I	
Seguridad Instrucciones r	1-3 para instalación y
conexión a tier	ra 3-4
Precauciones of	le seguridad5-6
Operación	
Panel de Contro	l9

Vamos a empezar a usar su Horno	10
Para ajuste del reloj	10
Características de función1	0-11
Para seleccionar potencia y tiempo o	
Cocción	12
Función de minuto automático	12
Función de mantener caliente	12
Función de Palomitas de Maíz	13
Función de Más/menos	13
Función de Descongelación Turbo	
Inverter	14
Consejos y Técnicas de	
Descongelación1	4-15
Función de Cocción por Sensor	16
Función de Recalentamiento por	

Operación

Recetas de Microondas 18 Función de Tiempo (Tiempo de Cocción/
Tiempo de reposo/Comienzo tardío)19
Consejos Rápidos20-21 Características de los alimentos22
Técnicas para cocinar22-23
Guía rápida de Operación27

Mantenimiento

Cuidado y Limpieza de su Horno de	
Microondas	24
Compra de Accesorios	24
Antes de solicitar Servicio Técnico	
Garantía Limitada y Directorio de	
Servicios al Consumidor	26

Información General

Guía de utensilios7
Diagrama de Componentes del Horno8
Especificaciones28
Registro del usuario28

ANTES DE OPERAR ESTE PRODUCTO. LEA ESTE INSTRUCTIVO EN SU TOTALIDAD.

For English Instructions, turn over the book.

Para asistencia, por favor llame: 1-800-211-PANA(7262)

o envienos un correo electrónico a: consumerproducts@panasonic.com

o visitenos en www.panasonic.com (U.S.A)

Para asistencia, por favor llame: 787-750-4300

o visitenos en www.panasonicpr.com (Puerto Rico)

> F00037C51AP iPress0106-3 Impreso en China

Información de Seguridad del Horno de Microondas

Su seguridad y la seguridad de otros es muy importante.

Hemos proporcionado mensajes de seguridad importantes en este manual y en su aparato. Lea y obedezca siempre todos los mensajes de seguridad.



Éste es el símbolo de la alarma de seguridad, se utiliza para alertarle de los peligros potenciales que pueden dañar o lastimar a usted y a otros.

Todos los mensajes de seguridad seguirán el símbolo de la alarma de seguridad y cualquiera de las siguientes palabras PELIGRO, ADVERTENCIA o PRECAUCIÓN. Estas palabras significan:

A PELIGRO

Usted puede resultar lastimado o dañado seriamente si usted no sigue las instrucciones de inmediato.

A ADVERTENCIA

Usted puede resultar lastimado o dañado seriamente si usted no sigue las instrucciones.

A PRECAUCIÓN

PRECAUCIÓN indica una situación potencialmente peligrosa que, si no es evitado, puede dar lugar a lesión de menor importancia o moderada.

Todos los mensajes de seguridad le indicaran cuál es el peligro potencial, el cómo reducir la posibilidad de lesionarse y le advierte qué puede suceder al no seguir las instrucciones.



PRECAUCIONES PARA EVITAR POSIBLE EXPOSICIÓN EXCESIVA A ENERGÍA DE MICROONDAS

- (a) No intente hacer funcionar este horno con la puerta abierta ya que esto puede resultar peligroso. Es importante no anular o forzar los mecanismos de seguridad.
- (b) No coloque ningún objeto entre el panel frontal del horno y la puerta, ni permita que se acumule basura o residuos de limpiadores en las superficies de sellado.
- (c) No haga funcionar el horno si está dañado, es importante que la puerta del horno abra y cierre apropiadamente y no haya ningún daño en:
 - (1) la puerta (combada),
 - (2) bisagras y seguro de la puerta (rotos o sueltos),
 - (3) sellos de las puertas y superficies de sellado.
- (d) El horno no deberá ser ajustado o reparado por ninguna persona, excepto el personal de servicio debidamente calificado.

Gracias por comprar este Horno de Microondas Panasonic.

Su horno de microondas es un artículo para cocinar y usted debe usarlo con tanto cuidado como usa una estufa o cualquier otro artículo para cocinar. Cuando utilice este aparato eléctrico, se deben seguir precauciones básicas de seguridad, incluyendo las siguientes:

INSTRUCCIONES IMPORTANTES DE SEGURIDAD

Para reducir el riesgo de quemaduras, descarga eléctrica, incendio, heridas a personas o exposición excesiva a energía de microondas:

1. Lea todas las instrucciones antes de usar el aparato.

 Lea y siga las "PRECAUCIONES PARA EVITAR POSIBLE EXPOSICIÓN EXCESIVA A ENERGÍA DE MICROONDAS" específicas, que se encuentran abajo.

 Este aparato debe ser conectado a tierra. Conecte solamente a la toma eléctrica debidamente conectada a tierra. Vea las "INSTRUCCIONES PARA CONEXIÓN A TIERRA" que se encuentran en la página 4.

. Como cualquier otro aparato para cocinar, NO DEJE el horno desatendido cuando

esta en uso.

 Instale o ubique este aparato solamente de acuerdo con las instrucciones de instalación que se encuentran en la página 3.

No cubra ni tape ninguna de las rendijas de este aparato.

 No almacene o use este aparato en exteriores. No use este aparato cerca del agua - por ejemplo, cerca del fregadero de la cocina, en una base mojada, o cerca de una alberca, y similares.

8. Use este aparato sólo para los fines para los que fue hecho, tal como se describen en este manual. No use químicos o vapores corrosivos en este aparato. Este tipo de horno está específicamente diseñado para calentar o cocinar alimentos. No fue diseñado para uso industrial o de laboratorio.

 Cuando limpie las superficies de la puerta y el horno que vienen juntas al cerrar la puerta, use solamente jabones no abrasivos o detergentes suaves aplicados con

una esponia o con tela suave.

10. No permita a los niños usar este aparato, a menos que sean supervisados muy de cerca por un adulto. No asuma que porque un niño ha dominado una habilidad para cocinar el/ella puede cocinar todo sin supervisión.

11. **No** use este aparato si tiene dañado el cordón o la clavija, si no está trabajando

adecuadamente, o si ha sido dañado o se ha dejado caer.

12. **No** sumergir en agua el cable o la clavija.

13. Mantenga el cable lejos de superficies calientes.

14. **No** deje el cable colgando en el borde de la mesa o mostrador.

 Este áparato debe recibir mantenimiento sólo de personal calificado. Contacte las instalaciones de servicio autorizadas más cercanas para revisión, reparación o ajuste.

16. Algunos productos, tales como los huevos completos y contenedores sellados - por ejemplo frascos de vidrio cerrados - pueden explotar y no deben ser calentados en

este horno.

17. Para reducir el riesgo de incendio en la cavidad del horno:

- (a) No sobrecocine los alimentos. Preste atención cuidadosa al aparato. El papel, plástico u otros materiales combustibles son colocados dentro del horno para facilitar la cocción pero si no se utilizan adecuadamente esto puede producir incendio en su horno.
- (b) Quite los sujetadores de alambre de las bolsas de papel o plástico antes de colocar la bolsa en el horno.
- (c) Si el material dentro del horno se enciende, mantenga la puerta del horno cerrada, apáguelo y desconecte el cable eléctrico o apague la energía en el switch (braker) del fusible o del circuito.

(d) No use la cavidad con propósitos de almacenaje. No deje productos de papel, utensilios de cocina o alimentos en la cavidad cuando no esté en uso.

▲ INSTRUCCIONES IMPORTANTES DE SEGURIDAD

(continuación)

18. Liquidos muv calientes

Liquidos como agua, cafe o te pueden ser sobrecalentadosabajo del punto de ebullicion sin mostrar una ebulliion o signos de este. No siempre burbujea cuando el recipiente se retira del Microondas. ESTO PUEDE RESULTAR EN UNA EBULLICIÓN REPENTINA DEL LÍQUIDO MUY CALIENTE CUANDO SE INTRODUZCA UNA CUCHARA U OTRO UTENSILIO DENTRO DEL LÍQUIDO. Para reducir el riesgo de heridas a personas:

- (a) REVUELVA EL LÍQUIDO ANTES Y DURANTE EL CALENTAMIENTO.
- (b) NO caliente el agua y aceite, o las grasas juntas. La película del aceite atrapará vapor, y puede causar una erupción violenta.
- (c) No utilice recipientes de lados rectos con cuello angosto.
- (d) Luego del calentamiento, deje el recipiente dentro del horno de microondas por un corto tiempo antes de retirarlo.
- 19. NO cocine directamente sobre el plato giratorio. Este puede guebrarse. causando lesiones o daño al horno.

ADVERTENCIA

PARA EVITAR EL RIESGO DE DESCARGA ELÉCTRICA:

NO quite el panel externo del horno. Las reparaciones se deben hacer solamente por una persona calificada del servicio.

PARA REDUCIR EL RIESGO DE EXPOSICIÓN A **ENERGÍA DE MICROONDAS:**

NO altere o haga ningún ajuste o reparación a la puerta, al alojamiento del panel de control, interruptores entrecruzados de seguridad o a cualquier otra parte del horno.

PARA EVITAR EL RIESGO DE INCENDIO:

- 1. NO opere el horno vacío. La energía de microondas se reflejará continuamente a través del horno si los alimentos o agua no están presentes para absorber energía. Esto puede dañar el horno y resultar en peligro de incendio.
- 2. NO almacene los materiales inflamables al lado, encima. o dentro del horno.
- 3. NO seque telas, periódicos u otros materiales en el horno. Pueden incendiarse.
- 4. NO golpee ni pegue en el panel de control. Pueden causarse daños a los controles.
- 5. NO use productos de papel reciclado, a menos que en la etiqueta del papel se indique que puede ser utilizado en horno de microondas, ya que pueden contener impurezas que pueden causar chispas y/o incendios cuando se usen.

PARA EVITAR EL RIESGO DE QUEMADURAS:

Las manoplas para tomar cosas calientes siempre deben ser utilizadas cuando se retiren cosas del horno. El calor se transfiere de los alimentos calientes a los contenedores para cocinar y de los contenedores a la bandeja de cristal. La bandeja de cristal puede estar muy caliente después de sacar los contenedores para cocinar del horno.

RDE ESTAS INSTRUCCION

Para el uso apropiado del horno lea las precauciones restantes de seguridad e instrucciones de funcionamiento.







A INSTRUCCIONES IMPORTANTES DE SEGURIDAD

(continuación)

Plato giratorio de cristal

1. NO opere el horno sin el anillo giratorio y el plato de cristal en su lugar.

2. NO ponga a funcionar el horno sin el plato giratorio de cristal ensamblado completamente en el cubo de la impulsión. El cocinar de manera incorrecta podría resultar en daños al horno. Verifique que el plato giratorio de cristal sea enganchado correctamente y observe que la rotación sea apropiada cuando presiona Encender. **Notá:** El plato giratorio puede dar vuelta en cualquier dirección.

3. Utilice solamente el plato giratorio diseñado específicamente para este horno. NO substituya ningún otro plato giratorio.

4. Si el plato giratorio esta caliente, permita que se enfríe antes de la limpieza o de colocar en agua.

5. NO cocine directamente en el plato giratorio. Coloque siempre el alimento en

un plato seguro para microondas.

6. Si el alimento o el utensilio en el plato giratorio toca las paredes del horno, ocasionará que el plato giratorio deje de moverse, el plato de cristal rotará automáticamente en la dirección opuesta.

Anillo Giratorio

1. El anillo giratorio y el piso del horno se deben limpiar con frecuencia para prevenir ruido excesivo. 2. Siempre vuelva a colocar el anillo giratorio y el plato de cristal en sus

posiciones apropiadas.

3. El anillo giratorio se debe utilizar siempre para cocinar junto con el plato de cristal.



A INSTRUCCIONES DE INSTALACIÓN

Examine Su Horno

Desempaque el horno, quite todo el material de empaque y examine que su horno no tenga ningún daño, tal como abolladuras, seguros de la puerta rotos o resquebrajaduras en la puerta. Notifique inmediatamente a su distribuidor si el horno está dañado.

Ubicación del Horno

1. El horno debe ser colocado en una superficie plana y estable. Ponga la superficie delantera de la puerta tres pulgadas o más del borde superior contrario para evitar inclinar accidentalmente el horno de microondas durante su uso normal. Para su operación apropiada, el horno debe tener suficiente corriente de aire. Deje 7,6 cm (3-pulgadas) de espacio de ambos lados del horno y 2,5 cm (1-pulgada) de espacio en la parte superior del horno.

(a) **NO** bloquear la ventilas del aire. Si es bloqueada la ventilación del aire durante la operación, el horno puede sobrecalentarse y quemarse.

(b) **NO** coloque el horno cerca de una superficie húmeda caliente, tal como un registro de gas o eléctrico.

(c) NO haga funcionar el horno cuando la humedad del lugar es excesiva.

2. Este producto está diseñado para uso doméstico exclusivamente. No está aprobado su uso para uso comercial, marino o en algún otro vehículo móvil.

Instalación

1. NO bloquee las salidas de aire. Si se bloquean durante la operación, el horno puede recalentarse. Si el horno se recalienta, un dispositivo de seguridad termal apagará el horno. El horno seguirá siendo inoperable hasta que se haya enfriado.

2. Si el horno está diseñado para ser instalado o empotrado en un gabinete de pared usando los accesorios proporcionados por el distribuidor local de Panasonic, siga todas las instrucciones anexadas con los accesorios.



▲ INSTRUCCIONES DE INSTALACIÓN

(continuación)

A ADVERTENCIA

-EL USO INAPROPIADO DE LA CLAVIJA PARA CONEXIÓN A TIERRA PUEDE RESULTAR EN RIESGO DE DESCARGA ELÉCTRICA.

Si es necesario usar un cable de extensión, use solamente cable de extensión de tres hilos que tenga una clavija de tres entradas para conectar a tierra, y un receptor de tres ranuras que acepte la clavija del aparato. El calibre marcado en el cable de extensión debe ser igual o mayor al calibre eléctrico del aparato.

Instrucciones de Conexión a Tierra

ESTE APARATO DEBE SER CONECTADO A TIERRA. En el caso de un corto circuito. la conexión a tierra reduce el riesgo de una descarga eléctrica proporcionando una línea de escape para la corriente eléctrica. Este aparato está equipado con un cable y clavija para conexión a tierra. La claviia debe ser conectada en un receptor que esté instalado adecuadamente v conectado a tierra.

- Enchufe en la conexión correctamente instalado y puesto a tierra de 3 entradas.
- NO guite el diente de tierra.
- NO utilice adaptador.

Suministro Eléctrico

- 1. Se provee un cable de suministro eléctrico corto para reducir los riesgos resultantes de enredarse o tropezarse con un cable más largo.
- 2. Juegos de cable más largos o extensiones están disponibles y pueden utilizarse si se usan con cuidado. NO deie el cable colgar sobre el borde de la mesa o mostrador.
- 3. Si se usa un cable más largo o extensión, (1) el calibre eléctrico marcado en el juego de cable o extensión debe ser al menos tan grande como el calibre eléctrico del aparato. (2) el cable de extensión debe ser de tres hilos del tipo de conexión a tierra, y (3) un cable más largo debe ser arreglado de tal forma que no caiga sobre la cubierta del mostrador o de la mesa donde pueda ser jalado por niños o alguien pueda tropezarse accidentalmente

Requerimientos de cableado

El horno debe estar en un circuito separado. Ningún otro aparato debe compartir el circuito con el horno. Si lo hace el fusible del circuito puede estallar, el bloqueador del circuito trabarse o la comida cocinarse más lento que en los tiempos recomendados en este manual. El horno debe ser conectado en un enchufe a tierra de al menos 20 A 120 V. 60 Hz. Donde se encuentre un enchufe estándar de 2 entradas será responsabilidad - v obligación - del consumidor reemplazarlo por un enchufe a tierra de 3 entradas. El voltaje usado debe ser el mismo al especificado en el horno de microondas (120 V, 60 Hz) Usar un voltaje más alto es peligroso y puede resultar en fuego u otro accidente causando daño al horno. Usar un bajo voltaje dará como resultado un cocinado más lento.

Panasonic NO es responsable por cualquier daño que haya resultado del uso del horno con un voltaje distinto al especificado.

Interferencia de Radio o Televisión

- 1. La operación de su horno de microondas puede causar interferencia en su radio, TV o equipo similar.
- 2. Cuando hay interferencia, se puede reducir o eliminar tomando las siguientes medidas:
 - (a) Limpie la puerta y las superficies selladoras del horno.
 - (b) Ponga el radio, TV, etc. lo más lejos posible del horno de microondas.
 - (c) Use una antena instalada adecuadamente para obtener una recepción de señal más fuerte.

A

Sugerencias Útiles

Siga Estas Precauciones de Seguridad Cuando Cocine en Su Horno

IMPORTANTE

La cocción adecuada depende del tiempo designado y del peso de los alimentos. Si usa una porción menor de la recomendada y cocina por el tiempo para la porción recomendada, puede resultar en un incendio. Si ocurre un incendio, ponga el horno en posición de apagado y manténgalo cerrado. Desconecte la energía eléctrica o desconecte la caja de fusibles o el panel de control.

1) ENLATADO CASERO / ESTERILIZACIÓN / ALIMENTOS DESHIDRATADOS / PEQUEÑAS CANTIDADES DE ALIMENTOS

- No use el horno para el enlatado casero o para calentar cualquier frasco cerrado. La presión aumentará y el frasco puede explotar. Su horno no puede mantener los alimentos a la temperatura apropiada de enlatado.
- No use el horno de microondas para esterilizar objetos (mamilas de bebe, etc). Es difícil mantener el horno a la temperatura necesaria para la esterilización.
- No seque carne, hierbas, frutas o vegetales en su horno. Pequeñas cantidades de alimento o alimentos con bajo contenido de humedad se pueden secar, quemar o incendiarse.

2) PALOMITAS DE MAÍZ

Las palomitas de maíz deben prepararse en un recipiente para palomitas de maíz adecuado para horno de microondas. Palomitas de maíz para horno de microondas que se preparan en su propio paquete también están disponibles. Siga las instrucciones del fabricante de palomitas de maíz y use una marca adecuada para la potencia de su horno de microondas. Nunca deje desatendido el horno cuando prepare palomitas de maíz.

PRECAUCIÓN: Cuando use palomitas de maíz para microondas previamente empacadas siga las instrucciones recomendadas en el paquete o utilice la tecla de palomitas de maíz (revise página 13). Si no se siguen estas instrucciones, las palomitas de maíz pueden no reventar adecuadamente o pueden encenderse y causar un incendio.

Nunca deje el horno desatendido, cuando están reventando las palomitas. Permita que la bolsa de palomitas se enfríe antes de abrirse, abra siempre la bolsa lejos de su cara y cuerpo para prevenir quemaduras del vapor.

3) FREIR CON MUCHA GRASA

 NO trate de freír con mucha grasa en su horno de microondas. Cocinar aceites puede estallar en flamas y puede causar daño al horno y quizá acabar en quemaduras. Los utensilios de microondas pueden no ser útiles para soportar la temperatura del aceite caliente, y podrían romperse

4) ALIMENTOS CON PIELES NO POROSAS

- NO COCINE / RECALIENTE HUEVOS ENTEROS, CON O SIN LA CÁSCARA. La acumulación del vapor en huevos enteros puede hacerlos estallar, y es causa de daño al horno o causa de lesión. Recalentar los huevos duros REBANADOS y cocinar los huevos revueltos es seguro.
- Papas, manzanas, calabazas completas y salchichas son ejemplos de alimentos con pieles no porosas. Estos tipos de alimentos deben ser perforados antes de cocinarlos en microondas para evitar que estallen.
 PRECAUCIÓN: Cocinar papas secas o viejas pueden ocasionar fuego.

Sugerencias Útiles

(continuación)

5) BANDEJA DE CRISTAL / UTENSILIOS DE COCINA / PAPEL ALUMINIO

- Los utensilios para cocinar se calientan durante la cocción en microondas. Use soportes para lo caliente, cuando saque los utensilios del horno o cuando quite tapas o cubiertas de envoltura de plástico de los utensilios de cocina, para evitar quemaduras.
- La bandeja de cristal se calentará durante la cocción. Debe permitirse que se enfríe antes de manejarla o antes de colocar productos de papel, tales como platos de papel o bolsas de palomitas de maíz para microondas, para cocinar.
- Al usar papel aluminio en el horno, permita por lo menos de 1 pulgada (2,5 centímetros) de espacio entre el papel aluminio y las paredes del horno o la puerta interior.
- Platos con adornos metálicos no deberán ser usados, ya que puede producirse arco eléctrico.

6) TOALLAS DE PAPEL / TELAS

 No use toallas de papel o telas que contengan fibras sintéticas en su tejido. La fibra sintética puede causar que la toalla se incendie. Utilice toallas de papel bajo supervisión.

7) BANDEJA DORADORA / BOLSAS PARA COCINAR EN HORNO

- Las bandejas doradoras o asadoras son diseñadas para cocinar en microondas solamente. Siempre siga las instrucciones dadas por el fabricante.
 No precaliente la bandeja doradora más de 6 minutos.
- Si se utiliza una bolsa para cocinar en Microondas, prepare de acuerdo a las instrucciones del paquete. No use sujetadores de alambre para cerrar la bolsa, en su lugar utilice sujetadores de plásticos, un cordón de algodón, o la tira del extremo abierto de la bolsa.

8) TERMÓMETROS

 No use termómetros convencionales para alimentos en su horno. Puede producir arco. Están disponibles termómetros seguros para microondas para carne y dulce.

9) FÓRMULA DE BEBÉ / ALIMENTOS PARA BEBÉ

No caliente la fórmula o los alimentos para el bebé en el horno de microondas.
 El tarro o la superficie de cristal del alimento pueden parecer tibios mientras que el interior puede resultar tan caliente que podría ocasionar quemaduras en la boca y esófago del bebe.

10) RECALENTAMIENTO DE PRODUCTOS DE REPOSTERÍA

• Cuando recaliente productos de repostería, compruebe la temperatura de cualquier relleno antes de comer. Algunos alimentos tienen rellenos que se calientan más rápidamente y puedan resultar extremadamente calientes, mientras que la superficie sigue siendo tibia al tacto (Ej. Donas de jalea).

11) GUÍA DE USO GENERAL DEL HORNO / PUERTA DEL HORNO

• No use el horno por cualquier razón que no sea la preparación de alimentos.




Guía de Utensilios

Papel aluminio Papel	o pueden ser utilizadas
Papel aluminio protección para proteger las partes más del unicamente Pueden ocurrir chispas si el alun	
como resultado.	minio se encuentra muy a del horno y dañar el horno
Platos para dorar Si Los platos para dorar están dise microondas solamente. Cheque dorador para instrucciones y el g No precaliente por más de 6 min	la información del plato gráfico de calentamiento.
Bolsas de papel común No Pueden incendíarse.	v suidada da las fabricantos
Utensilios de cocina: Etiquetados "Para uso de microondas" Si Cheque las instrucciones de uso para calentar en microondas. Alc pueden tener en la parte posterio uso de microondas".	gunos utensilios de cocina or del plato "Seguro para
Utensilios de cocina no etiquetados Si o No Utilice PRUEBA DE RECIPIENT	TES abajo.
Platos desechables de poliéster o cartón Si Algunos alimentos congelados e platos. Pueden ser comprados e comestibles	
Comida rápida en caja de cartón con mango No El mango de metal puede ocasio de metal	onar chispas.
Comida congelada en en bandeja de metal No El metal puede causar chispas y	dañar su horno.
Comida congelada en bandeja para Microondas Si Caliente solo una bandeja en el	
Tarros de vidrio No La mayoría de los tarros de cristicalor. No utilice para cocinar o r	recalentar.
Cerámica y vidrios refractarios Si Ideales para cocción en horno de dorador (Vea PRUEBA DE REC	CIPIENTE abajo).
Utensilios de metal para hornear No Pueden causar chispas que caus	as y dañar su horno.
Bolsas para Siga las instrucciones del fabrica	isen fuego en el horno. ante. Cierre la bolsa con el
Utilice para alimentos cocidos y	para cocinar alimentos que
Toallas y servilletas Si Utilice para calentar rollos y sand	iwiches, solo si esta
Toallas y servilletas Productos de papel reciclado pue	
de papel reciclado que pueden ocasionar chispas.	·
Papel pergamino Si para uso en microondas, microon convencionales.	ndas/ convección y hornos
Plástico: Utensilios de cocina seguros para microondas Si, utilice con precaución microondas", Siga las instruccion fabricante. Algunos contenedores de microondas no son convenien contenidos de grasa o azúcar. El calientes pueden ocasionar que el	nes y recomendaciones del s plásticos seguros para uso tres para alimentos con altos calor de los alimentos el plástico se deforme.
Plástico, Melamine No Este material absorbe la energía se calientan.	·
Tazas de unicel Si, use con precaución Tazas de unicel Si, use con temperaturas. Utilice para recaler a un bajo nivel de temperatura.	ntar alimentos únicamente
Plástico para envolver Si retener la textura y prevenir que se etiquetada "Conveniente para Ca Revise las instrucciones del empa	salpique. Deberá ser alentar en Microondas".
Termómetros apropiados para hornos de microondas Si Use solamente termómetros para microondas.	a carne y dulce seguros para
Termómetro convencional No No convenientes para el uso en la causar chispas y calentarse.	
Papel encerado Si Utilice como cubierta para preven textura.	nir salpicaduras y retener la

PRUEBA DE RECIPIENTES

Prueba de seguridad del recipiente para uso en Horno de Microondas: Coloque un vaso de agua en el Horno de microondas junto al recipiente que será probado, caliente por un minuto a Potencia P10. Si el recipiente es seguro para el uso en microondas debe estar frío y el agua debe estar caliente. Si el recipiente esta caliente es porque absorbió alguna energía del microondas y no debe ser utilizado. Esta prueba no puede ser utilizada para recipientes plásticos. 7


Diagrama de Componentes del Horno



- a Ventilaciones de Aire Externas
- **(b)** Ventilaciones de Aire Internas
- © Sistema de Cierre de Seguridad de la Puerta
- d Ventilaciones de aire externas
- Panel de control
- f Placa de Identificación


- h Aro de Rodillo
- (i) Película de Barrera contra el Calor/Vapor (no extraer)
- (i) Cubierta del guía de ondas (no remover)
- Region Botón para abrir la puerta
- ① Etiqueta de Menú

Control Panel



Bip:

Cuando una tecla es presionada correctamente, se escuchará un "bip". Si una tecla es presionada y no escucha un "bip", significa que la unidad no aceptó o no pudo aceptar la instrucción. El horno hará 2 veces "bip" entre las etapas programadas. Al final de cada programa completado, el horno hará 5 veces "bip".





- Conéctelo a una toma de red con conexión a tierra.
- 2. Se mostrará el mensaje "WELCOME TO PANASONIC..." (Bienvenido a Panasonic) en la pantalla.



Reloj

Ejemplo: Para ajustar 11:25 am o pm

1.	 Presione la tecla de Reloj. ▶ punto comienza a parpadear.
2. 1 1 2 5	 Fije la hora correcta del día. ▶ 11:25 aparece en la pantalla indicadora.
3.	 Presione la tecla de Reloj. > punto deja de parpadear. La hora está ingresada y ubicada en la pantalla indicadora.

NOTAS:

- Para reiniciar el reloj. Repetir el paso 1 hasta el 3.
- El Reloj seguirá marcando la hora siempre que siga recibiendo alimentación eléctrica.
- El Reloj visualiza el horario normal basado en las 12 horas, no utiliza el horario militar.
- 4. El horno no funcionará mientras los dos puntos estén parpadeando.



CARACTERÍSTICAS DE FUNCIÓN

Esta función única de su horno microondas PANASONIC le permite establecer las características iniciales (No de cocción del horno), por ejemplo, SEGURO PARA NIÑOS, VELOCIDAD DEL TEXTO, ELECCIÓN DE IDIOMA (INGLÉS, FRANCÉS O ESPAÑOL), y muchas más. Encontrará más información a continuación.

Function	• Presione Funciones .
2. O a 9 Presione	 Presione la selección con las teclas numéricas (véase el cuadro de la página siguiente).
1 a 3 Presione	 Presione la selección con las teclas numéricas (véase el cuadro de la página siguiente).

 Si desea otras opciones, repita los pasos 1 a 3 para acceder a funciones adicionales.



Características de función (continuación)

SELECCIÓN DE IDIOMA El horno le permite elegir el idioma de la pantalla: inglés, francés o alemán. Function Cuando se enchufa por primera vez la visualización aparece en español. (7) *1 ENGLISH

La visualización aparece en inglés. 2 FRANÇAIS • La visualización aparece en francés. 3 ESPAÑOL → La visualización aparece en español. SELECCIÓN DE LIBRA/KILO Este horno posee mediciones de peso en el sistema inglés y en el sistema métrico. Cuando se enchufa, el horno visualiza el peso en el sistema métrico. → El peso se puede ajustar en onzas/libras (Sistema Inglés). ►*1 LB 2 KG → El peso se puede ajustar en g/kg, (Métrico). VELOCIDAD DE PALABRAS La velocidad del desplazamiento de palabras de la Ventana de visualización se puede acelerar o retrasar. 1 RAPIDO → Las palabras se desplazan rápidamente. *2 MFDIO → La velocidad de desplazamiento vuelve a su aiuste inicial. 3 DESPACIO → Las palabras se desplazan lentamente. ACCIÓN DE MENÚ La ventana de acción del menú le ayuda a programar su horno indicando mediante mensajes-quías el próximo paso que se tiene que dar. Cuando se familiarice con su horno, la aparición de mensajes-guías se puede apagar. → Aparecerá el Mensaie-Guía. *1 SI 2 NO No aparecerá el Mensaje-Guía. SEGURO PARA NIÑOS SI/NO El horno posee una función de Seguro para Niños que impide el uso del horno por parte de los niños. Esta función no asegura la puerta. → Se ha ajustado Seguro para Niños y no se aceptará la 1 SI operación. → Se ha anulado el Seguro para Niños. →*2 NO **BIP SI/NO** Si desea que el horno funcione sin sonido, éste se puede eliminar. ➤*1 SI → El sonido "Bip" se reactivará. ➤ 2 NO → El sonido "Bip" no se escuchará. **BIP RECORDATORIO SI/NO** Un sonido recordatorio funciona para recordarle que se debe extraer los alimentos del horno, después de la finalización de la cocción. → El sonido "Bip" de recordatorio trabajará. 1 SI ➤*2 NO → El sonido "Bip" de recordatorio no trabajará. HORA DE VERANO SI/NO 1 SI → La hora del día se adelantará una hora. ➤ *2 NO → La hora del día volverá a su ajuste original. **RELOJ SI/NO** La visualización del reloj se puede colocar en "apagado". → La visualización del reloj aparecerá en la Ventana de *1 SI Visualización. 2 NO → La visualización del reloj no aparecerá en la Ventana de Visualización. Se memorizará la hora del día mientras la pantalla esté apagada. MODO DE DEMOSTRACION El modo demo está diseñado para la visualización en las tiendas. En este modo, el funcionamiento del horno se puede demostrar sin que ésta produzca microondas. 1 SI → El horno está en modo demo. >> *2 NO → El horno no está en modo demo.

^{*} MODO PREDETERMINADO



Ejemplo: Para cocinar en P6 durante 1 minuto 30 segundos.

1. Power Level (10 Levels) Presione 5 veces	Presione la tecla de potencia hasta que el nivel de potencia deseado aparezca en la ventana de visualización.	
2.	Seleccione el tiempo de cocción.	
3. Start	 Presione ENCENDER. ➤ El tiempo de cocción aparece y empieza 	

la cuenta regresiva.

Pulse	Nivel de Potencia
1 vez	P10 (ALTO)
2 veces	P9
3 veces	P8
4 veces	P7 (MEDIO-ALTO)
5 veces	P6 (MEDIO)
6 veces	P5
7 veces	P4
8 veces	P3 (MEDIO-BAJO)/DESC.
9 veces	P2
10 veces	P1 (BAJO)

NOTAS:

- Para la cocción de más de una etapa, repetir los pasos 1 y 2 para cada etapa de cocción antes de presionar la tecla Encender. Cuando esta funcionando, sonarán dos "bips" entre cada etapa de la programación. Sonarán 5 "bips" al final de toda la secuencia.
- Cuando se selecciona la potencia P10 (ALTO) para la primera etapa, podrá empezar en el paso 2.
- Cuando seleccione Nivel de potencia 10 (ALTO), el máximo tiempo programable es de 30 minutos. Para otros niveles de potencia, el tiempo máximo es 99 minutos y 99 segundos.
- Para el recalentamiento, utilizar P10
 (ALTO) para líquidos, P7 (MEDIO-ALTO)
 para la mayoría de los alimentos y P6
 (MEDIO) para los alimentos densos.
- Para descongelamiento P3 (MEDIO-BAJO).

No sobrecocine los alimentos. Este horno requiere menos tiempo para cocinar que las unidades viejas. Sobrecocinar puede ocasionar que los alimentos se sequen y puede causar fuego. La potencia de cocción del horno de microondas le indican la cantidad de potencia de microondas disponible para cocinar.

Las Funciones automáticas han sido proporcionadas para su conveniencia. Si los resultados no son convenientes para su preferencia individual o el tamaño del servicio es otro que el listado en la página 17, por favor refiérase a la cocción manual.



Minuto Automático

Esta función le permite ajustar y/o añadir tiempos de cocción fácilmente en múltiplos de un minuto.

Para seleccionar tiempo de cocción:

Quick	Seleccione Minuto Automático hasta seleccionar el tiempo deseado de cocción (hasta 10 minutos) aparece en la ventana de visualización. El nivel de potencia pre- seleccionado es P10.
2. Start	Presione <i>Encender</i> . Inicia la cocción y el tiempo empieza a transcurrir. Al final de la cocción, sonarán 5 "bips".

NOTAS:

- Para utilizar otros niveles de potencia, presionar de nivel de Potencia y a continuación minuto automático.
- Si utiliza minuto automático no podrá utilizar teclas de numéricas.
- La tecla de Minuto automático puede ser utilizado para agregar más tiempo durante la cocción manual.

Mantener Caliente

Esta característica permite mantener caliente los alimentos después de 30 minutos de cocinar.

Ejemplo: Para mantener 2 tazas de salsa calientes

1. Keep Warm	Presione la tecla de Mantener Caliente.
2. 0 a 9	Selecciones el tiempo de calentamiento, hasta 30 minutos.
3.	 Presione Encender. Mantener Caliente iniciará. El tiempo en la ventana de visualización empezará el conteo.

NOTA:

La función de Mantener caliente puede ser programada como paso final después de que el tiempo de cocción ha sido manualmente programado. Esta no puede ser utilizada en combinación con funciones de sensor o automáticas.



Palomitas de Maíz

Eiemplo: Para cocinar 99 g de nalomitas de maíz

paiomilas de maiz		
1. Popcom	Presione la tecla de palomitas de maíz hasta que el peso deseado aparezca en la ventana de visualización. Presionar Peso 1 vez 99 g (3,5 oz) 2 veces 85 g (3,0 oz) 3 veces 50 g (1,75 oz)	
2. More/ Less	• (vea la función de Más/Menos .)	
Opcional		
3. Start	 Presione ENCENDER. Tras varios segundos, se muestra el tiempo de preparación en la ventana de visualización y comienza a transcurrir el tiempo. 	

NOTAS PARA PALOMITAS DE MAÍZ:

- Cocine una bolsa de palomitas cada
- 2. Ponga la bolsa en el interior del horno de acuerdo a las instrucciones del fabricante.
- 3. Inicie a cocinar las palomitas a la temperatura ambiente.
- Permita que las palomitas de maíz preparadas permanezcan cerradas por unos minutos.
- Abra la bolsa cuidadosamente para prevenir quemaduras, el vapor puede
- 6. No recaliente las palomitas que no se hicieron ni bolsas re-usadas.

NOTA:

Si el paquete de palomitas es de un peso diferente al listado, siga las instrucciones que aparecen en el paquete. Nunca deje el paquete desatendido. Pare el horno cuando las palomitas tardan en estallar de 2 segundos a 3 segundos.

Sobrecocinar puede causar un incendio.

NOTA:

Cuando se preparen varias bolsas una tras otra, el tiempo de preparación puede variar ligeramente. Esto no afecta al resultado de las palomitas.





Time Tunción Más/Menos

Para Palomitas de Maíz:

Utilizando la función de Más/Menos. los programas para cocinar palomitas pueden ser ajustados por más largo o corto tiempo si se desea.

1 pulsación = Agrega aproximadamente 10 segundos 2 pulsaciones = Agrega aproximadamente 20 segundos 3 pulsaciones = Reduce aproximadamente 10 segundos 4 pulsaciones = Reduce aproximadamente 20 segundos 5 pulsaciones = Aiuste original

Presione la tecla Más/Menos antes de presionar *Encender*.

Para el Recalentamiento/Cocción por

Las preferencias para el punto de cocción varían de acuerdo a la persona. Luego de utilizar la función de Recalentamiento/ Cocción por sensor algunas veces, podrá decidir si prefiere que su comida sea cocinada en

1 pulsación = Más (Agrega aproximadamente 10% de tiempo) 2 pulsaciones = Menos (Reduce aproximadamente 10% de tiempo) 3 pulsaciones = Selección original

un punto de cocción diferente.

Presione la tecla Más/Menos antes de presionar *Encender*.



Descongelación Turbo Inverter

Esta función le permite descongelar carne, productos avícolas y pescado con sólo introducir el peso.

Ejemplo: Para descongelar 1,5 kg de carne.

Coloque la comida en un plato adecuado para el uso de microondas.

Inverter Turbo Defrost	Presione la tecla de Descongelación Turbo Inverter.
2.	Introducir el peso utilizando las teclas de número.
3. Start	Presione ENCENDER. El tiempo de descongelado aparece y empieza la cuenta regresiva. A la mitad del descongelamiento, cuando suene "bip". Apáguelo, reacomode la comida, remueva las áreas descongeladas o protéjalas con láminas de aluminio.

Tabla de Conversión:

Siga la tabla para convertir onzas o cientos de una libra en décimos de una libra. Para utilizar la Descongelación Turbo Inverter, ingrese el peso de los alimentos en libras (1,0) y décimos de una libra (0,1). Si una pieza de carne pesa 1,95 libras o 1 libra 14 onzas, ingrese 1,9 libras.

Onzas	Centésimos de	Décimos de
	una libra	una libra
0	0,01 - 0,05	0,0
1 - 2	0,06 - 0,15	0,1
3 - 4	0,16 - 0,25	0,2
5	0,26 - 0,35	0,3
6 - 7	0,36 - 0,45	0,4
8	0,46 - 0,55	0,5
9 - 10	0,56 - 0,65	0,6
11 - 12	0,66 - 0,75	0,7
13	0,76 - 0,85	0,8
14 - 15	0,86 - 0,95	0,9



'a' Consejos y Técnicas de Descongelación

Preparación para Congelar:

- 1. Congelar carnes, carne de ave y pescado en paquetes con sólo 1 capa o 2 capas de alimentos. Colocar papel encerado entre las capas.
- 2. Empacar en envolturas de plástico resistentes (etiquetadas "Para Congelador") o papel congelador.
- 3. Remover tanto aire como sea posible.
- 4. Coloque el sello de seguridad con fecha y etiqueta.

Para Descongelar:

- 1. Quitar la envoltura. Esto ayuda a que la humedad se evapore. Los jugos de los alimentos pueden calentarse y cocinar los alimentos.
- 2. Colocar los alimentos en un plato adecuado para uso de microondas.
- 3. Colocar el lado de la grasa del asado hacia abajo. Colocar el lado de la pechuga del ave entera hacia abajo.
- 4. Seleccionar potencia y tiempo mínimo para que estos alimentos debajo sean descongelados.
- 5. Drene los líquidos durante el descongelamiento.
- 6. Voltee los alimentos durante el descongelamiento.
- 7. Proteja bordes y extremos si es necesario (Vea Técnicas de Cocción).

Después de Descongelar:

- 1. Los artículos grandes pueden estar congelados del centro. La descongelación será completada durante el TIEMPO DE REPOSO.
- 2. Reposo, cubierta, instrucciones después del tiempo de reposo en página 15.
- Enjuague los alimentos como se indica en el cuadro.
- 4. Artículos que han sido colocados en capas deberán ser enjuagados por separado o tener mayor tiempo de reposo.



Consejos y Técnicas de Descongelación

(continuación)

Alimento	Tiempo de descongelación (min/kg) (P3)	Durante la descongelación	Después de la des Tiempo de reposo	congelación Enjuagar (agua fría)
Pescado y Marisco [hasta 1,4 kg (3 libras)] Carne de Cangrejo Bistecs de Pescado	6 4 a 6	Romper y separar/Reordenar Dar la vuelta	5 minutos	Sí
Filetes de Pescado Raciones preparadas Pescado entero	4 a 6 4 a 6 4 a 6	Dar la vuelta/Reordenar/Proteger extremos Separar/Extraer trozos congelados Dar la vuelta		
Carne Carne Molida	4 a 5	Dar la vuelta/Extraer parte descongelada/ Proteger bordes	10 minutos	
Asados [1,1 kg-1,8 kg (2 ¹ / ₂ lb-4 lb)]	4 a 8	Dar la vuelta/Proteger extremos y superficie descongelada	30 minutos en frigorífico	
Chuletas/Bistec	6 a 8	Dar la vuelta/Volver a ordenar/ Proteger extremos y superficie descongelada		
Costillas/T-bone	6 a 8	Dar la vuelta/Volver a ordenar/ Proteger extremos y superficie descongelada	5 minutos	No
Carne de Cocido	4 a 8	Separar/Volver a ordenar/ Extraer partes descongeladas	o minatos	110
Hígado (cortado finamente)	4 a 6	Extraer el líquido/Dar la vuelta/ Separar piezas		
Tocino, rebananas	4	Dar la vuelta		
Carne de Ave Pollo entero [hasta 1,4 kg (3 libras)]	4 a 6	Dar la vuelta/Proteger	20 minutos en frigorífico	
Cortes	4 a 6	Separar/Dar la vuelta/ Extraer partes descongeladas	5 minutos	Sí
Trozos	4 a 6	Separar/Dar la vuelta/Proteger	10 minutos	01
Aves de Caza	6 a 8	Dar la vuelta/Proteger		
Pechuga de Pavo [2,3 kg-2,7 kg (5 lb-6 lb)]	6	Dar la vuelta/Proteger	20 minutos en frigorífico	

Recalentamiento por Sensor

La función del sensor le permite recalentar alimentos previamente cocidos y refrigerados sin necesidad de ajustar el tiempo. El horno lo hace todo por usted.

Ejemplo: Para recalentar un plato de comida

1. Sensor Reheat	Presione la tecla de Recalentamiento por Sensor.
2. More/ Less Opcional	• (ver Función Más/Menos) (• página 13)
3. Start	• Presione <i>ENCENDER</i> . ➤ Empieza la cocción.

El cocinado estará completo cuando suenen los 5 "bips". (Cuando el vapor es detectado por el Sensor Genius y 2 bips suenen, el tiempo de cocción restante aparecerá en la ventana de visualización.)

NOTAS:

Cazuelas - Añadir de 3 cucharadas a 4 cucharadas de líquido; cubrir con una tapa o con un envoltorio de plástico. Remover cuando suenen los 5 "bips". Alimentos Envasados - Vaciar el contenido en una cazuela o en un cuenco; cubrir el recipiente con una tapa o con un envoltorio de plástico. Después de calentar, retirar el envoltorio de plástico y dejar reposar.

Plato de Comida - Colocar la comida en un plato; cubrir con mantequilla, salsa, etc. Después de calentar, retirar el envoltorio de plástico y dejar reposar. Seguir los consejos para la cocción con sensor, además de los consejos abajo indicados:

NO:

- NO calentar pan o alimentos de pastelería. Utilizar la potencia y el cronómetro manual para estos alimentos.
- NO calentar alimentos crudos o no cocinados.
- NO utilizar si el horno está caliente.
- 4. NO utilizar para bebidas.
- NO utilizar para alimentos congelados.



Cocción por Sensor

Esta función del sensor le permite cocinar cualquier cantidad de alimentos pulsando un botón. El horno lo hace todo por usted.

Ejemplo: Para cocinar Entradas Congeladas

Sensor Cook Presione 4 veces	 Presione hasta que el número de la categoría deseada aparezca en la ventana de visualización. 	
2. More/ Less Opcional	• (ver Función Más/Menos) (• página 13)	
3. Start	• Presione <i>ENCENDER</i> . ➤ Empieza la cocción.	

El cocinado estará completo cuando suenen los 5 "bips". (Cuando el vapor es detectado por el Sensor Genius y 2 bips suenen, el tiempo de cocción restante aparecerá en la ventana de visualización.)

Para obtener mejores resultados con la función Sensor GENIUS, siga las siguientes recomendaciones:

ANTES de calentar/cocinar:

- La temperatura ambiente de la habitación donde se encuentra el Horno debe ser menor a 35°C (95°F).
- 2. El peso de los alimentos puede exceder 110 g (4 onzas).
- Asegúrese que la bandeja de cristal, la parte exterior de los contenedores para cocinar y dentro del horno de microondas, se encuentren secos antes de colocar la comida en el horno. Los residuos de humedad al convertirse en vapor pueden engañar el sensor.
- 4. Cubra los alimentos con tapa, o con plástico autoadherible ventilado. Nunca use contenedores plásticos sellados fuertemente – estos previenen que el vapor escape y causa que los alimentos se sobrecocinen.

DURANTE el calentamiento/cocción:
NO abrir la puerta del horno hasta que suenen 2 "bips" y el tiempo aparezca en la Pantalla de Visualización porque se produciría una cocción inadecuada ya que el vapor de los alimentos no permanece en la cavidad del horno. Una vez que el temporizador inicia la cuenta atrás, la puerta del horno puede abrirse para remover, dar la vuelta los alimentos, cubrir, disponer de nuevo los alimentos, mezclar o añadir alimentos.

DESPUÉS del calentamiento/cocción: Todos los alimentos deben permanecer cubiertos durante un determinado tiempo.



Tabla de Cocción con Sensor

Receta	Porción/Peso	Consejos
1. Cereal	40 g - 80 g (1/ ₂ taza - 1 taza)	Coloque un platón especial para microondas dentro del horno. Siga las instrucciones del fabricante para preparar una rápida avena.
2. Salchicha	2 enlaces - 8 enlaces	Seguir las instrucciones del fabricante para la preparación de las salchichas precocinadas. Colocar de forma radial.
3. Omelet	2 huevos, 4 huevos	Seguir la receta básica para tortilla de la pagina 18.
4. Entradas Congeladas	225 g - 900 g (8 oz - 32 oz)	Siga las instrucciones del fabricante para la preparación. Después de 2 tonos, revuelva o cambie. Tenga cuidado al quitar la cubierta de la película después de cocinar. Aléjelo de usted al quitar la cubierta para evitar quemaduras de vapor. Si es necesario tiempo adicional continúe cocinando manualmente.
5. Pizza congelada (individual)	225 g (8 oz)	Seguir las instrucciones del fabricante.
6. Papas	1 - 4 patatas (170 g - 225 g) (6 oz - 8 oz cada uno)	Perfore cada papa con un tenedor 6 veces alrededor de toda la superficie. Coloque la papa o papas alrededor del borde del plato giratorio alineado de una toalla de papel por lo menos a 1 pulgada (2,5 cm) de distancia. No cubrir, déjelo estar 5 minutos para completar la cocción.
7. Vegetales Frescos	110 g - 450 g (4 oz - 16 oz)	Todos los trozos deben ser del mismo tamaño. Lave profundamente, agregue 1 cucharada de agua por cada ½ taza de vegetales, y cubra sin cerrar con la tapa o una envoltura de plástico perforada. No agregue sal o mantequilla hasta después de cocinar.
8. Vegetales Congelados	170 g - 450 g (6 oz - 16 oz)	Lave profundamente, agregue 1 cucharada de agua por cada ½ taza de vegetales, y cubra sin cerrar con la tapa o una envoltura de plástico perforada. No agregue sal o mantequilla hasta después de cocinar. (No se recomienda para los vegetales en mantequilla o salsa.) Después de 2 tonos, revuelva o cambie.
9. Pasta	56 g - 225 g (2 oz - 8 oz)	Coloque la pasta con una capa de agua caliente dentro un plato especial para Microondas. Cubra sin cerrar con la tapa o una envoltura de plástico perforada.



Recetas de Microondas

OMELET (TORTILLA)

Omelet básica (Tortilla)

cucharada de mantequilla o margarina

2 huevos

cucharadas de leche sal y pimienta negra, si así se desea

Calentar mantequilla de 9 pulgadas del plato del pie, 20 segundos en Potencia P10, o hasta derretirla. Gire el plato para cubrir todo el fondo con mantequilla. Mientras tanto, combine el resto de los ingredientes en un tazón separado, bata todo y colóquelo en el plato del pay. Cocine, cubierto con plástico auto adherible ventilado, utilice la selección OMELET. Deje en reposo 2 minutos. Con una espátula, afloje los bordes del omelet del plato, doble en 3 para servir. Siempre utilice huevos revueltos.

1 servicio

Tiempo aprox. 4 minutos.

NOTA: duplicar la cantidad de ingredientes para un omelet (tortilla) de 4 huevos.

GUISOE

Pastel de carne

1 kilo de ternera picada

125 g de guisantes congelados, ya descongelados

60 g de cebolla picada

1 cucharada sopera de caldo de carne

1/2 cucharada pequeña de curry en polvo

1/4 cucharada pequeña de sal

1/4 cucharada pequeña de pimienta negra molida

500 g de puré de papa

En una cacerola 2 cuartos. revuelva el fondo de la carne y cocina por 5 minutos – 7 minutos a Potencia P6 o hasta que la carne este cocida, remueva dos veces. Agregar el resto de los ingredientes, excepto las papas. Remueva bien, y después unte uniformemente las papas uniformemente en la parte de arriba. Cubrir con una tapa o plástico auto adherible ventilado y cocine en Potencia P5 por 16 minutos – 18 minutos.

Macarrones con queso

60 g de mantequilla

2 cucharadas soperas de cebolla picada

1 diente de ajo picado

60 g de harina

Servicios: 4

1 cucharada pequeña de mostaza seca

1 cucharada pequeña de sal

cucharada pequeña de pimienta negra molida

500 ml de leche

500 g de queso cheddar rallado

225 g de macarrones, hervidos y colados

120 g de pan molido

1 cucharada pequeña de pimiento dulce

En una cacerola 2 cuartos. derretir la mantequilla por 40 segundos a potencia P10. Agregue cebolla y ajo y cocine por 1 minuto a Potencia P10. Revuelva en harina, mostaza, sal y pimienta, y gradualmente agregue leche. Cocine por 3 minutos – 4 minutos en potencia P10 hasta que la salsa espese, remueva una vez. Agregue el queso cheddar, revuelva a fondo. Vierta y revuelva la salsa en los macarrones, en una cacerola 3 cuartos. Agregue al final migajas de pan y paprika. Cubra con una tapa o plástico auto adherible ventilado. Cocine en potencia P6 por 16 minutos – 18 minutos. Servicios: 6

Guiso de carne y macarrones

1 kilo de carne picada

1 cebolla pequeña picada

½ pimiento verde picado

250 g de apio picado

2 latas (425 g) de salsa de tomate

375 ml de agua

250 g de caracolas sin cocer

1 cucharada pequeña de perejil 1/2 cucharada pequeña de sal

1/4 cucharada pequeña de pimienta negra molida

125 g de queso cheddar rallado

Desmenuce la carne picada en una cacerola 3 cuartos. Cocine por 5 minutos – 7 minutos a potencia P6 o hasta que la carne este cocida. Revuelva 2 veces. Revuelva en cebolla, pimienta y apio. Cocine por 3 minutos – 4 minutos a Potencia P10. Remueva con el resto de los ingredientes, excepto el queso. Cubra con una tapa o plástico auto adherible ventilado. Cocine en Potencia P6 por 16 minutos – 18 minutos. Rocíe el queso. Cubra y deje en reposo 5 minutos.

Servicios: 4-6

Atún

1 lata (170 g) de atún desecado y desmigado

1000 g de fideos hervidos y escurridos 1 lata (290 g) de crema de champiñón

1 lata (110 g) de champiñones hervidos y escurridos

1 paquete (450 g) de guisantes congela dos, ya descongelados

190 ml de leche

250 g de papas fritas trituradas

125 g de queso cheddar rallado

En una cacerola 3 cuartos. combine atún, fideos, sopa, champiñones, chícharos y leche; mezcle bien. Cubra con tapa o plástico auto adherible ventilado. Cocine en potencia P6 por 16 minutos – 18 minutos. Cubra con papas fritas y queso después de servir. Servicios: 4-6

•



Temporizador

Esta característica le permite programar el tiempo después de que la cocción ha sido completada y programar el horno con un tiempo de espera y/o un comienzo tardío.

Para usar como temporizador en la cocina:

Ejemplo: Para contar 5 minutos		
1. Timer	Presione Tiempo.	
2. 5 0 0	• Indique la cantidad de tiempo (hasta 99 minutos y 99 segundos).	
3.	 Presione Encender. ➤ El Temporizador realizará la cuenta regresiva. No se realizará ningún tip de cocción 	

Para fijar un tiempo de espera o tiempo de reposo:

Ejemplo: Después de la cocción dejar reposar el alimento durante 3 minutos(MEDIO)

minutos(MEDIO)		
Power Level (10 Levels) Presione 5 veces	 Indique el programa de cocción deseado (ver página 12 para instrucciones). 	
2. 3 0 0	Seleccione el tiempo deseado de cocción utilizando las teclas numéricas.	
3. Timer	• Presione Tiempo .	
4. 5 0 0	Indique la cantidad de tiempo (hasta 99 minutos y 99 segundos).	
5.	 Presione Encender. Después de la cocción el tiempo de reposo empezará a contar en forma descendente sin que el horno esté 	

funcionando.

PRECAUCIÓN.

Si la lámpara del horno está encendida cuando se está utilizando el temporizador, el horno esta programado incorrectamente. Detenga el horno inmediatamente y vuelva a leer las instrucciones.

Para programar un comienzo tardío:

Ejemplo: Para un comienza tardío de 5 minutos, y cocción en potencia P6 for 3 minutos.

1. Timer	• Presione Tiempo .	
5 0 0	• Introduzca la cantidad de tiempo de espera que se desea utilizando las teclas numéricas: (hasta 99 minutos y 99 segundos)	
3. Power Level (10 Levels) Presione 5 veces	 Seleccione el programa de cocción (ver página 12 para instrucciones). 	
3 0 0	Seleccione el tiempo deseado de cocción utilizando las teclas numéricas.	
5. Start	 Presione Encender. Cuando el tiempo demorado comience con la cuenta regresiva, y éste haya finalizado, la cocción iniciará. 	

NOTA:

- Cuando cada etapa finalice, sonarán 2 bips como indicación. Al final del programa, el horno hará 5 bips.
- Si la puerta del horno es abierta durante el Tiempo de Reposo, El Cronometro de Cocina o el comienzo tardío, el tiempo en la ventana de visualización seguirá contando el tiempo.
- 3. El tiempo de reposo y Comienzo tardío no pueden ser programados antes de ninguna función automática. Esto previene que el inicio de temperatura de los alimentos de antes de descongelar o al comienzo de la cocción. Un cambio en la temperatura de inicio puede causar resultados inapropiados.



Consejos Rápidos

ALIMENTOS	POTENCIA	TIEMPO	INSTRUCCIONES
Tocino, Separado, 1 libra (450 g)	P10 (ALTO)	30 s	Quite la envoltura. Después de calentar, use una espátula de plástico para separar las rebanadas.
Azúcar Morena, Suavizada 1 taza (250 ml)	P10 (ALTO)	20 s a 30 s	Coloque 1 taza de azúcar morena (250 g) en el plato con una rebanada de pan o un trozo de manzana. Cubra con envoltura plástica.
Para ablandar la Mantequilla, 1 varilla, 1/4 de libra (110 g)	P3 (MEDIO-BAJO)	1	Retirar el envoltorio y poner la mantequilla en un recipiente adecuado para el microondas.
Para derretir la Mantequilla, 1 varilla, 1/4 de libra (110 g)	P6 (MEDIO)	1 min. 30 s a 2 min.	Retirar el envoltorio y poner la mantequilla en un recipiente adecuado para microondas cubierto con un envoltorio de plástico.
Chocolate, Derretido, 1 cuadro (28 g) Chocolate, Derretido, 1/2 taza de chispas (125 ml)	P6 (MEDIO) P6 (MEDIO)	1 min. a 1 min. 30 s 1 min. a 1 min. 30 s	Quite la envoltura y coloque el chocolate en el plato, remueva antes de añadir más tiempo. El chocolate conserva su forma aún cuando se suaviza.
Coco, Pan Tostado, 1/2 taza (125 ml)	P10 (ALTO)	1 min.	Colóquelos en un molde de tarta o en tazón. Remueva cada 30 segundos.
Queso Crema, Suavizado, 225 g (8 oz)	P3 (MEDIO-BAJO)	1 min. a 2 min.	Quite la envoltura y colóquelo en un plato.
Para Dorar La orilla de la Carne, 450 g (1 libra)	P10 (ALTO)	4 min. a 5 min.	Deshebre en un colador seguro para uso de microondas en otro plato. Cubra con papel auto adherible. Revolver 2 veces. Drenar la grasa.
Para cocinar Vegetales, Frescos (225 g) (1/2 lb)	P8	3 min. 30 s a 4 min.	Todos los trozos deben ser del mismo tamaño. Lave profundamente, agregue 1 cucharada de agua por cada ½ taza de vegetales, y cubra sin cerrar con la tapa o una envoltura de plástico perforada. No agregue sal o mantequilla hasta después de cocinar.
Descongelar (285 g) (10 oz)	P8	3 min. 30 s a 4 min.	Lave profundamente, agregue 1 cucharada de agua por cada ½ taza de vegetales, y cubra sin cerrar con la tapa o una envoltura de plástico perforada. No agregue sal o mantequilla hasta después de cocinar. (No se recomienda para los vegetales en mantequilla o salsa.)
Enlatados (430 g) (15 oz)	P8	3 min. 30 s a 4 min.	Vacíe los contenedores en un tazón para uso seguro en microondas. No Cubrir.

Consejos Rápidos

(continuación)

ALIMENTOS	POTENCIA	TIEMPO	INSTRUCCIONES
Para cocinar Papa Horneada, (170 g - 225 g) (6 oz - 8 oz cada una) 1	P8 P8	3 min. 30 s a 4 min. 6 min. a 7 min.	Perforar cada papa con un tenedor 6 veces alrededor de toda la superficie. Colocar la papa o papas alrededor del borde de la bandeja de cristal (giratoria), al menos 1 pulgada (2,5 cm) separado, No cubrir. Deje en reposo 5 minutos para completar la cocción.
Para vapor en las toallas de mano – 4	P10 (ALTO)	20 s a 30 s	Remojar en agua, después escurrir el exceso. Coloque en un plato seguro para uso en microondas. Caliente. Presente inmediatamente.
Helado, Suavizado, 1/2 galón (2 litro)	P3 (MEDIO-BAJO)	1 min. a 1 min. 30 s	Revise frecuentemente para evitar que se derrita.
Taza de agua 1 taza (250 ml) 2 taza (500 ml)	P10 (ALTO) P10 (ALTO)	1 min. 30 s a 2 min. 2 min. 30 s a 3 min.	Los líquidos calientes pueden hacer erupción si no son mezclados con aire. No caliente líquidos en su horno de microondas sin removerlos primero.
Taza de leche 1 taza (250 ml) 2 taza (500 ml)	P7 (MEDIO-ALTO) P7 (MEDIO-ALTO)	1 min. 30 s a 2 min. 2 min. 30 s a 3 min.	
Para asar nueces, 11/2 taza (375 ml)	P10 (ALTO)	3 min. a 4 min.	Esparcir las nueces a 9 pulgadas (23 cm) en un plato de pay seguro para uso de microondas. Revolver ocasionalmente.
Para asar Semillas de Sésamo, 1/4 taza (60 ml)	P10 (ALTO)	2 min. a 2 min. 30 s	Colocar en un tazón pequeño seguro para uso en microondas. Remover 2 veces.
Para piel de tomates, (uno a la vez)	P10 (ALTO)	30 s	Colocar el tomate en un tazón seguro para el uso en microondas que contenga agua hirviendo. Enjuagar y Pelar. Repita para cada tomate.
Para Quitar Olores, del Horno	P10 (ALTO)	5 min.	Combine 1 taza (250 ml) a 1 ½ (375 ml) taza de agua con el jugo y piel de un limón en una taza pequeña. Después de calentar limpie el interior del horno con una tela suave.


Características de los Alimentos

Huesos y Grasas

Tanto los huesos como la grasa afectan la cocción. Los huesos pueden causar cocción irregular. La carne cercana a las puntas de los huesos puede sobrecocinarse en tanto que la carne ubicada bajo un hueso largo, tal como un hueso de jamón, puede resultar crudo. Grandes cantidades de grasa absorben energía de microondas y la carne cercana a estas áreas puede sobrecocinarse.

Densidad

Alimentos porosos, como panes, pasteles o rollos toman menos tiempo para cocinar que los alimentos pesados y densos como panas y asados. Cuando



Cantidad

Dos papas toman más tiempo para cocinarse que una papa. Así como se aumenta la cantidad de alimento se incrementa el tiempo de cocción. Cuando se cocinan cantidades pequeñas de alimento, tales como una o dos papas, no deje el horno desatendido. El contenido de humedad en el alimento puede disminuir y puede resultar un incendio.

Forma

Tamaños uniformes se calentarán más uniformemente. El final delgado de un muslo se cocinará mas



rápido que un final carnoso. Para compensar las formas irregulares, coloque las partes delgadas hacia el centro del plato y las piezas gruesas hacia la orilla.

Tamaño

Piezas delgadas se cocinan más rápido que piezas gruesas.



Temperatura para Empezar: Los alimentos que están a temperatura ambiente toman menos tiempo para cocinarse que aquellos que están refrigerados o congelados.

Técnicas para Cocinar

Perforado

Alimentos con piel o

membrana deben ser perforados, abiertos o tener abierta una tira de piel antes de cocinar, para permitir que el vapor escape. Perforar las yemas y claras de los huevos enteros, almejas, ostiones, hígados de pollo, papas enteras y vegetales enteros. Las manzanas enteras o las papas sin pelar deben tener una tira de 2,5 cm de piel pelada antes de cocinarse. Perfore salchichas y embutidos.

Dorador

Los alimentos no tendrán la misma apariencia dorada que aquellos que son cocidos convencionalmente o aquellos alimentos que sean cocinados utilizando la

e la

característica de dorado. Las carnes y aves pueden ser bañados con salsa para dorar.

La salsa inglesa, salsa de barbacoa o la salsa para dorar con aplicador. Para usarlas combine la salsa para dorar con mantequilla o margarina derretidas; barnícelas antes de cocinarlas.

Para dorar panes o panecillos rápidos se para dorar panes o panecillos rápidos se puede usar azúcar morena en la receta

puede usar azúcar morena en la receta en lugar de azúcar granulada y se puede espolvorear la superficie con especies obscuras antes de hornear.

Espaciado

Alimentos individuales, tales como papas cocidas, panquecitos y aperitivos, se cocinarán más parejo si se



colocan en el horno a distancias iguales. Cuando sea posible, arregle los alimentos en un platón circular.



Técnicas para Cocinar

(continuación)

Cubierta

Como en la cocina convencional, el vapor se evapora durante la cocción por microondas. Las tapas de las cacerolas o cubiertas de plástico son usadas para sellar ajustadamente. Cuando utilice envoltura plástica, ventile la cubierta plástica doblando parte de la misma de una esquina del plato para permitir que el vapor escape. Suelte para tiempo de reposo. Cuando quite la cubierta plástica así como cualquier tapa de cristal, tenga cuidado de quitarla alejada de usted para evitar quemaduras por vapor. Varios grados de retención de humedad se obtienen también usando papel encerado o toallas de papel. Sin embargo, a menos que se especifique, las recetas se cocinan descubiertas.

Protección

Áreas delgadas de carnes o aves se cocinan más rápido que las porciones carnosas. Para evitar la sobrecocción, estas áreas delgadas pueden ser protegidas con tiras de papel de aluminio. Palillos de dientes de madera pueden ser usados para sostener al aluminio en su lugar.

▲ PRECAUCION se debe tener cuando se utilice papel aluminio. Arcos puede ocurrir si el papel aluminio está muy cerca de las paredes o puerta del horno, puede resultar en daños al horno.

Tiempo de Cocción

Un rango de tiempo de cocción se da en cada receta. El rango de tiempo se compensa por las diferencias incontrolables en las formas de los alimentos, la temperatura al inicio y las preferencias regionales. Siempre cocine los alimentos al tiempo mínimo de cocción dado en la receta y revise su termino. Si los alimentos están crudos, continue cocinando. Es mas fácil añadir tiempo a un producto crudo. Una vez que los alimentos están sobrecocinados, nada se puede hacer.

Remover

Remover es necesario normalmente durante la cocción por microondas. Hemos anotado cuando remover es necesario usando las palabras "una vez", "dos veces", "frecuentemente" u "ocasionalmente" para describir la cantidad de veces que es necesario remover.

Reacomodar

Reacomodar piezas pequeñas tales como partes de pollo, camarones, hamburguesas o cortes de puerco. Reacomode las piezas de las orillas al centro y piezas del centro a las orillas del plato.

Voltear

No es posible mezclar algunos alimentos para redistribuir el calor. A veces la energía del microondas se concentrará en un área del alimento. Para asegurar una cocción pareja, estos alimentos necesitan ser volteados. Voltee alimentos grandes, tales como asados o pavos, de medio giro mientras se cocinan.

Tiempo de Reposo

La mayoría de los alimentos continuarán cocinándose por conducción después de que el horno de microondas se apague; durante la cocción de la carne, la temperatura interna se incrementará de 3 °C a 8 °C si se permite el reposo, cubierto con papel de aluminio de 10 minutos a 15 minutos. Guisados y vegetales necesitan una cantidad menor de tiempo de reposo, pero este tiempo es necesario para permitir a los alimentos completar su cocción en el centro sin sobrecocinarse las orillas.

Prueba de Término

Las mismas pruebas de termino usadas en la cocción convencional pueden ser usadas para cocinar con microondas. La carne está lista cuando el tenedor se encaja o desliza entre las fibras. El pollo está listo cuando sus jugos son amarillo claro o el muslo se mueve libremente. Los pescados están listos cuando se separa la carne y está opaco.

Sobre la Seguridad del Alimento y Temperatura de Cocción

Revisar los alimentos para ver si están cocinados a las temperaturas recomendadas por el Departamento de Agricultura del los Estados Unidos.

TEMPERATURA DE LOS ALIMENTOS

71 °C (160 °F) ...para carne de puerco fresco, carne de res, carne blanca de ave sin huesos, pescado, alimentos de mar, huevos, y alimentos preparados congelados.

74 °C (165 °F) ...para lo demás, listo para recalentar lo refrigerado y deli, y comida fresca para llevar.

77 °C (170 °F) ...carne blanca de ave.

82 °C (180 °F) ... Carne roja de ave.

Para probar que esta hecho, inserte un termómetro de carne en un área espesa o densa, lejos de la grasa o hueso. NUNCA deje el termómetro en la comida durante la cocción, a menos que este sea aprobado para el uso en horno de microondas.



Cuidado y Limpieza de su Horno de Microondas

ANTES DE LIMPIAR:

Desenchufar en la toma mural del horno. En caso de que sea imposible, dejar el horno abierto para impedir que se ponga en marcha de manera accidental.

DESPUÉS DE LIMPIAR:

Asegúrese de que se vuelve a colocar el Aro de Rodillo y Bandeja de Cristal en la posición correcta, después pulsar la tecla Pausa/Cancelar para borrar la pantalla.

Etiqueta de Menú:

No remueva. Limpiar con un trapo suave.

Bandeia de cristal: Extraer y lavar con agua jabonosá v tibia o en un

lavaplatos.

del horno: Limpiar con un trapo suave. Para impedir daños en las piezas en operación en el interior del horno, no se debe permitir que el aqua entre por las aperturas de ventilación.

Las superficies exteriores

Interior del horno:

Limpiar con un trapo húmedo. Se puede utilizar un detergente suave si elhorno se ensucia mucho. No utilizar detergentes muy fuertes o abrasivos.

Panel de Control:

Cubierta con una película extraíble . para impedir ralladuras durante el envío.


(Consejo - Para extraer la película, aplicar cinta adhesiva transparente o de uso eléctrico en una esquina expuesta v

tirar suavemente.) * Si el panel de control se humedece, limpiar con un trapo seco y blando. No utilizar detergentes muy

fuertes o abrasivos.

Puerta de Horno:

Limpiar con un trapo blando cuando el vapor se acumule en el interior o alrededor del exterior de la puerta del horno. Durante la cocción, especialmente baio condiciones de mucha humedad, los alimentos expelen vapor. (Parte del vapor se condensará en las superficies más frías, como la puerta del horno. Esto es normal.) La superficie del interior está cubierta con una película que actúa como barrera contra el calor y vapor. No extraer.



Aro de Rodillo v el suelo de la cavidad del horno:

Limpiar la superficie inferior del horno con agua con un detergente suave o un producto de limpieza de ventanas y secar. El aro de Rodillo se puede lavar con agua con un detergente suave o con un producto para la limpieza de ventanas. Estas zonas se deberán mantener limpias para así evitar un ruido excesivo.

No quite la cubierta de la quía de las ondas:

Esta es importante para mantener la cubierta limpia de la misma manera que el interior del Horno.

ES IMPORTANTE MANTENER EL HORNO LIMPIO Y SECO. LOS RESIDUOS Y LA CON-DENSACIÓN DE VAPOR DEL ALIMENTO PUEDEN CAUSAR ENMOHECIMIENTO Y / O ACUMULACIONES QUE DAÑEN AL HORNO. DESPUÉS DE USARSE EL HORNO LIMPIE CON UN TRAPO SECO TODAS LAS SUPERFICIES INCLUYENDO LAS ABERTURAS DE VENTILACIÓN. HENDIDURAS DEL HORNO. Y DEBAJO DE LA BANDEJA DE CRISTAL.

DESCRIPCIÓN DE LAS PARTES

Instrucciones/Manual de uso (este libro)

Bandeia de Cristal

Aro de Rodillo

NÚMERO DE LAS PARTES

F00037C51AP

F06014W00AP

F06014M00AP

(NN-H735/H765/SN776)

(NN-H935/H965)

F290D9330AP

Compra de Accesorios

Compra de piezas, accesorios e instructivos en línea de todos los productos Panasonic visite nuestro Sitio Web en: http://www.pasc.panasonic.com

o envíe su pedido al E-mail: npcparts@us.panasonic.com

Usted también puede contactarnos directamente en:

1-800-332-5368 (teléfono) 1-800-237-9080 (fax solamente) (Lunes-Viernes 9 a.m. a 8 p.m.)

Compañía de Servicio Panasonic

20421 84th Avenue South,

Kent. WA 98032

(Aceptamos Visa, Mastercard, Discover Card, American Express y Cheques personales)

Para usuarios de Equipo Teleescritor: 1-866-605-1277



Antes de Acudir a Servicio

Estos casos son normales:

Mi horno de microondas causa interferencia con mi televisor

En algunos radios y televisores puede ocurrir interferencia cuando usted cocine con su horno de microondas. Esta interferencia es similar a la interferencia por pequeños aparatos eléctricos como batidoras, aspiradoras, secadoras de aire, esto no indica ningún problema.

Se acumula vapor en la puerta del horno v aire caliente sale de las reiillas de ventilación.

Durante la cocción los alimentos despiden vapor. La mayoría de este vapor es removido por el aire que circula en la cavidad del horno, sin embargo, algo de vapor se condensará en las superficies frías tales como la puerta del horno. Esto es normal. Después de usarse el horno se debe limpiar en seco (ver página 24).

PROBLEMA

POSIBLE CAUSA

ACCIÓN

El horno no se pone en marcha.

El horno no está enchufado de manera segura.

Extraer el enchufe de la toma, esperar 10 segundos y volver a enchufar.

se ha fundido o disparado. Existe un problema con la toma eléctrica.

El magneto térmico o el fusible Reiniciar el magneto térmico o cambiar el fusible. Enchufar otro electrodoméstico en la toma para comprobar si

La puerta no está cerrada completamente.

ésta funciona correctamente. Cerrar bien la puerta del horno.

La tecla Encender no ha sido presionada. Presione **Encender**.

El horno no empieza

Ya se había introducido otro programa en el horno.

Presione *Pausa/Cancelar* para anular el programa anterior e introducir un programa nuevo.

El programa no es correcto.

Programar otra vez de acuerdo con las instrucciones de Operación.

La tecla Pausa/Cancelar se presionó accidentalmente.

Programar el horno otra vez.

El plato giratorio tambalea.

a cocinar.

El plato giratorio no está colocado correctamente en el Aro del Rodillo o existen alimentos debaio del Aro del Rodillo.

Retire la Bandeia de Cristal v el Aro de Rodillo. Limpie con un paño húmedo y reajuste el Aro de Rodillo v la Bandeia de Cristal correctamente.

Cuando el horno está funcionando. la Bandeia de Cristal produce ruidos.

El(Los) Anillo(s) del Rodillo y el fondo del horno están sucios.

Limpie estas partes de acuerdo al Cuidado y Limpieza de su Horno de Microondas (ver página 24)

Se muestra la palabra "LOCK" (seguro) en la pantalla.

EI SEGURO PARA NIÑOS está activado.

Véase la tecla de Funciones en la página 11.

GARANTÍA LIMITADA Y DIRECTORIO DE SERVICIOS AL CONSUMIDOR

COMPAÑÍA ELECTRÓNICA DE CONSUMIDORES PANASONIC, DIVISIÓN DE PANASONIC CORPORACION DE NORTE AMÉRICANA One Panasonic Way Secaucus, New Jersey 07094, USA COMPAÑÍA DE VENTAS PANASONIC, DIVISIÓN DE PANASONIC PUERTO RICO, INC.

Ave. 65 de Infantería, Km. 9.5 Parque Industrial San Gabriel Carolina, Puerto Rico 00985

Garantía Limitada del Horno Microonda Panasonic

Cobertura de la Garantía Limitada

Si su producto no funciona adecuadamente debido a defecto en los materiales o en la fabricación, la Compañía Electrónica de Consumidores Panasonic (Panasonic Consumer Electronics Company) o la Compañía de Ventas Panasonic (Panasonic Sales Company) (referidos colectivamente como "el garante"), por la duración del período que se menciona más abajo, el cual comienza en la fecha de compra original ("período de garantía"), hará uso de dos opciones (a) reparar su producto con partes nuevas o reparadas, o (b) reemplazarlo por un producto nuevo o uno reparado. La decisión de reparar o reemplazar el producto será tomada por el garante.

TODAS LAS PARTES (EXCEPTO EL TUBO MAGNETRÓN)
TUBO MAGNETRÓN

PARTES TRABAJO 1 (UN) AÑO 1 (UN) AÑO 5 (CINCO) AÑOS 1 (UN) AÑO

Durante el período de la garantía de "Trabajo" no habrán cobros por trabajo. Durante el período de lá garantía de "Partes" no habrán cobros por las partes. Usted debe llevar o enviar por correo su producto durante el período de garantía. Esta garantía sólo se aplica a productos comprados y pagados en Estados Unidos y Puerto Rico. Esta garantía se extiende sólo al comprador original de un producto nuevo y no a quien lo compre de segunda mano. Para el servicio de garantía se necesita un recibo de compra o alguna otra prueba de la fecha de compra original del producto.

Servicio de Entrega o Envío por Correo

Para el Servicio de Entrega o Envío por Correo en Estados Unidos, por favor llame al 1-800-211-PANA(7262) o visite nuestro Sitio Web Panasonic: http://www.panasonic.com

Para asistencia en Puerto Rico llame a la Compañía de Ventas Panasonic (Panasonic Sales Company) al (787)-750-4300 o al fax (787)-768-2910.

Garantía Limitada, Límites y Exclusiones

Esta garantía SÓLÓ CUBRE fallas debido a defectos en los materiales o en la fabricación y NO CUBRE vidrios, partes plásticas, o algún tipo de termómetro (si es que está incluído), deterioros o rasguños normales o daños cósmeticos. La garantía TAMPOCO CUBRE daños producidos por el transporte o fallas causadas por productos no proporcionados por el garante, o fallas que hayan sido el resultado de accidentes, mal uso, abuso, negligencia, plaga de insectos, mal embalaje, mala aplicación, alteración, instalación defectuosa, ajustes de montaje, mal ajuste del control del consumidor, mantenimiento inapropiado, sobretensión en la línea de conducción eléctrica, daños en la iluminación, modificaciones, o uso comercial (por ejemplo en un hotel, oficina, restaurante u otros usos comerciales), arriendo del producto, reparado por cualquier otro servicio que no sea el Servicio Técnico de la Fábrica o algún Servicio Técnico Autorizado, o cualquier daño que se la atribuya a la mano de Dios. NO EXISTEN GARANTÍAS ESCRITAS EXCEPTO LAS QUE SE ENUMERAN MÁS ABAJÓ COMO "COBERTURA DE GARANTÍA LIMITADA". EL GARANTE NO SE HACE RESPONSABLE POR DAÑOS FORTUÍTOS O IMPORTANTES QUE SE PRODUZCAN POR EL USO DE ESTE PRODUCTO O DEBIDO A CUALQUIER VIOLACIÓN DE ESTA GARANTÍA. (por ejemplo, esto excluye daños por pérdida de tiempo, el costo que tiene si se necesita que alguien remueva o reinstale el aparato, o los viajes desde y al servicio técnico. Los puntos mencionados no son sólo los únicos, se mencionan a modo de explicación.) TODAS LAS GARANTÍAS ESCRITAS E IMPLICITAS, INCLUÍDAS LAS GARANTÍAS DE COMERCIALIZACIÓN, SON LIMITADAS, SEGUN EL PERIODO DE LA GARANTÍA LIMITADA. Algunos estados no permiten la exclusión o restricción de daños importantes o fortuítos, o restricciones sobre cuanto tiempo dura una garantía implícita, de esa forma las exclusiones no se aplicarían a usted. Esta garantía le da derechos legales específicos y usted puede tener también otros derechos que varien de un estado a otro. Si un problema con este producto sucede durante o

problema no es solucionado a su satisfacción, entonces usted puede escribir al Departamento de Asuntos del Consumidor del Garante a la dirección que se menciona para el garante.

LAS PARTES Y SERVICIOS QUE LA GARANTÍA LIMITADA NO CUBRE, SON DE SU RESPONSABILIDAD.

después del período de garantía, usted puede contactarse con su distribuidor o con el Servicio Técnico. Si el

Directorio de Servicio a Cliente

Para obtener información de producto y asistencia de funcionamiento; Localizar a su Distribuidor o Centro de Servicio más cercano; comprar piezas y accesorios; o hacer pedidos en Servicio a Cliente, visite nuestro Sitio Web en: http://www.panasonic.com/consumersupport
o, contáctenos en: http://www.panasonic.com/contactinfo

Usted puede también contactarnos directamente al: 1-800-211-PANA(7262), Lunes-Viernes 9 am-9 pm; Sábado-Domingo 10 am-7 pm.

Para usuarios de Equipo Teleescritor: 1-877-833-8855

Servicio en Puerto Rico

Panasonic de Puerto Rico. Inc.

Avenida. 65 de Infantería, kilómetro. 9.5, Parque Industrial de San Gabriel, Carolina, Puerto Rico 00985 TEL. (787)750-4300, Fax (787)768-2910

GUÍA RAPIDA DE OPERACIÓN

Característica	Como Operarla
Para Poner el	Clock O a 9 Clock
Reloj en la Hora (☞ página 10)	Presione 1 vez. Registre la hora. Presione 1 vez.
Para Ajuste de	Power — — —
Potencia y Tiempo	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
(página 12)	Seleccione potencia. Establezca el tiempo de cocción. Presione.
Para Usar las teclas de Funciones	Function \rightarrow 0 a 9 \rightarrow 1 0 2 0 3
(☞ página 10)	Presione. Seleccione categoría. Seleccione.
Para Cocinar usando la	Pópcorn More/ Start
tecla de Palomitas (página 13)	Less
(pagina 13)	Registre el peso del paquete. Opcional. Presione.
Minuto Automático	Quick Min Start
(•página 12)	(hasta 10) Presione.
Para Recalentamiento	Sensor More/
usando la tecla Recalentamiento de	Sensor Reheat → More/ Less → Start
Sensor (página 16)	Presione 1 vez. Opcional. Presione.
Para Cocinar usando Teclas de Cocción de	e.x. Sensor More/ Loss Start
Sensor	COURT
(•página 16)	Seleccione categoría. Opcional. Presione.
Para Descongelar usando la tecla	Inverter
Descongelación	Turbo Defrost → 0 a 9 → Start
Turbo Inverter	Presione 1 vez. Fije el peso. Presione.
(página 14) Para utilizar	, ,
Mantener Caliente	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
(•página 12)	Presione 1 vez. Seleccione el tiempo de mantener caliente (hasta 30 minutos) Presione.
Para Usar como temporizador de	Timer → 0 a 9 → Start
cocina	
(☞ página 19)	Presione 1 vez. Introducir hora. Presione.
Para Establecer el Tiempo de Reposo	Registre el programa de Timer → 0 a 9 → Start
(☞ página 19)	Cocción deseado. Presione 1 vez. Introducir hora. Presione.
Para Establecer un	Registre el
Comienzo Tardío	Timer → 0 a 9 → programa de Conción descado
(☞ página 19)	Presione 1 vez. Introducir hora. Cocción deseado. Presione.



Especificaciones

	NN-H735/H765/SN776	NN-H935/H965	
Fuente de Energia:	120 V, 60 Hz		
Potencia Fuente de Poder:	12,7 A, 1 460 W		
Potencia de Cocción:*	1 250 W		
Dimensiones Exteriores	304 mm x 555 mm x 493 mm	356 mm x 606 mm x 493 mm	
(Alto x Ancho x Fondo):	(11 ¹⁵ / ₁₆ " x 21 ⁷ / ₈ " x 19 ⁷ / ₁₆ ")	(14" x 23 ⁷ / ₈ " x 19 ⁷ / ₁₆ ")	
Dimensiones Cavidad del Horno	228 mm x 418 mm x 470 mm	278 mm x 469 mm x 470 mm	
(Alto x Ancho x Fondo):	(9" x 16 ⁷ / ₁₆ " x 18 ¹ / ₂ ")	$(10^{15}/_{16}$ " x $18^{7}/_{16}$ " x $18^{1}/_{2}$ ")	
Frecuencia:	2 450 MHz		
Peso Neto:	Aprox. 14,3 kg (32 lb)	Aprox. 17,0 kg (37,5 lb)	
Accesorios Adecuado (Dimensiones Exteriores): (Unicamente para SN776) Los hornos de microondas de color blanco y negro no están diseñados para ser usados dentro de algún gabinete.	NN-TK729SF (Unicamente con hornos de microondas de acero inoxidable) 685 mm x 419 mm (27" x 16 ½") NN-TK739SF (Unicamente con hornos de microondas de acero inoxidable) 762 mm x 419 mm (30" x 16 ½")	No está diseñado para ser usado dentro de un gabinete	
Dimensión:	632 mm x 389 mm x 533,4 mm (24 ⁷ / ₈ " x 15 ⁵ / ₁₆ " x 21")		

^{*}Determinado de acuerdo a procedimientos contemplados en la norma IEC. Las especificaciones están sujetas a cambios sin previo aviso.

Registro de Usuario

El número de serie de este producto se localiza en la parte trasera del horno. Usted debería anotar el número de modelo y número de serie de este horno en el espacio indicado y guardar este libro como un registro permanente de su compra para futuras referencias.

Número de modelo:_____

Número de serie:_____

Fecha de Compra:

Compañía Electrónica de Consumidores Panasonic, División de Panasonic Corporacion de Norte Américana One Panasonic Way Secaucus, New Jersey 07094, USA

Compañía de Ventas Panasonic, División de Panasonic Puerto Rico, Inc.

Ave. 65 de Infanteria, Km. 9.5 Parque Industrial San Gabriel Carolina, Puerto Rico 00985

Matsushita Electric Industrial Co., Ltd.

Panasonic Artículos para el Hogar Hornos de Microondas de Shanghai

Av. Long Dong No. 898, Pu Dong, Shanghai, China 201203

Página web: http://www.panasonic.co.jp/global